



---

# TURBOCHARGER

	Page
DESCRIPTION.....	TC-2
PRECAUTIONS.....	TC-4
TROUBLESHOOTING.....	TC-5
TURBOCHARGER ELECTRICAL SYSTEM	
DIAGNOSIS (HZJ80).....	TC-7
TURBOCHARGER.....	TC-8

**TC**

## DESCRIPTION




TC0101  
TC0036

Systems which increase the amount of air sent to the engine are either turbocharger type (using exhaust gas to turn the turbine) or supercharger type (using the engine crankshaft, etc. to mechanically turn the pump, etc.). For LAND CRUISER and COASTER 1HD-T engine, the turbocharger type has been adopted.

The turbocharger is a device which increases engine output by introducing a greater amount of

air to the engine. This allows a proportional increase in the fuel that can be burned and hence raises the potential power output,

In other words, by installing a special turbocharger and providing a higher air than usual, engine output can be increased by increasing the average combustion pressure without increasing the engine speed,



TC0092

### Operation of Turbocharger


Exhaust gas acts on the turbine wheel inside the turbine housing, causing it to revolve. When the turbine wheel revolves, the impeller wheel which is located on the same shaft also revolves, compressing the intake air which has passed through the air cleaner. When expelled from the compressor housing the compressed air is supplied to the cylinders. When the engine speed increases, the exhaust gas volume increases and the turbine wheel revolutions increase (approx. 20,000 — 115,000 rpm), thus the turbocharged air pressure grows greater and engine output increases.

### Waste Gate Valve


If the turbocharged air pressure exceeds the prescribed air pressure, the flow of exhaust gas by-passes the turbine, controlling turbine wheel revolutions and turbocharged air pressure. This by-pass valve which controls the quantity of exhaust gas flowing to the turbine is called the waste gate valve. When the charged air pressure exceeds the prescribed pressure, the actuator operates, the waste gate valve opens and part of the exhaust gas by-passes the turbine. This causes a drop in the turbine revolution rate and controls the charged air pressure within the prescribed limits.

## PRECAUTIONS


1. Do not stop the engine immediately after pulling a trailer or high speed or uphill driving. Idle the engine for 20-120 seconds, depending on the severity of the driving condition.
2. Avoid sudden racing or acceleration immediately after starting a cold engine.
3. If the turbocharger is defective and must be replaced, first check for the cause of the defect in reference to the following items and replace parts if necessary:
  - Engine oil level and quality
  - Conditions under which the turbocharger was used
  - Oil lines leading to the turbocharger



4. Use caution when removing and reinstalling the turbocharger assembly. Do not drop it or bang it against anything or grasp it by easily-deformed parts, such as the actuator or rod, when moving it.
5. Before removing the turbocharger, plug the intake and exhaust ports and oil inlet to prevent entry of dirt or other foreign material.




6. If replacing the turbocharger, check for accumulation of sludge particles in the oil pipes and, if necessary, replace the oil pipes.
7. Completely remove the gasket adhered to the lubrication oil pipe flange and turbocharger oil flange.
8. If replacing bolts or nuts, do so only with the specified new ones to guard against breakage or deformation.



9. If replacing the turbocharger, put 20 cc (1.2 cu in.) of oil into the turbocharger oil inlet and turn the impeller wheel by hand to spread oil to the bearing.
10. If overhauling or replacing the engine, cut the fuel supply after reassembly and crank the engine for 30 seconds to distribute oil throughout the engine. Allow the engine to idle for 60 seconds.





11. If the engine is running with the air cleaner, case cover and hose removed, foreign particles entering will damage the wheels which run at extremely high speed.

## TROUBLESHOOTING

HINT: Before troubleshooting the turbocharger, first check the engine itself. (Valve clearance, engine compression, injection timing etc.)

### INSUFFICIENT ACCELERATION, LACK OF POWER OR EXCESSIVE FUEL CONSUMPTION

(Possible Cause)	(Check Procedure and Correction Method)
1. TURBOCHARGING PRESSURE TOO LOW	<p>Check turbocharging pressure. (See page TC-8)</p> <p><b>Turbocharging pressure:</b>  <math>0.50 - 0.65 \text{ kg/cm}^2</math>  <math>(7.1 - 9.2 \text{ psi}, 49 - 64 \text{ kPa})</math></p> <p>If the pressure is below specification, begin diagnosis from item 2.</p>
2. RESTRICTED INTAKE AIR SYSTEM	<p>Check intake air system, and repair or replace parts as necessary. (See page TC-8)</p>
3. LEAK IN INTAKE AIR SYSTEM	<p>Check intake air system, and repair or replace parts as necessary. (See page TC-8)</p>
4. RESTRICTED EXHAUST SYSTEM	<p>Check exhaust system, and repair or replace parts as necessary. (See page TC-8)</p>
5. LEAK IN EXHAUST SYSTEM	<p>Check exhaust system, and repair or replace parts as necessary. (See page TC-8)</p>
6. ERRATIC TURBOCHARGER OPERATION	<p>Check rotation of impeller wheel. If it does not turn or turns with a heavy drag, replace the turbocharger assembly.</p> <p>Check plays of turbine shaft. (See page TC-12)</p> <p><b>Axial play:</b> <math>0.13 \text{ mm (0.0051 in.) or less}</math>  <b>Radial play:</b> <math>0.18 \text{ mm (0.0071 in.) or less}</math></p> <p>If not within specification, replace the turbocharger assembly.</p>

---

**ABNORMAL NOISE**

---

(Possible Cause)

(Check Procedure and Correction Method)

**1. TURBOCHARGER INSULATOR  
RESONANCE**

Check for loose, improperly installed or deformed insulator mount bolts and nuts, and repair or replace as necessary.

**2. EXHAUST PIPE LEAKING OR  
VIBRATING**

Check for exhaust pipe deformation, loose mount bolts or a damaged gasket, and repair or replace as necessary.

**3. ERRATIC TURBOCHARGER  
OPERATION**

Refer to item 6 of INSUFFICIENT ACCELERATION, LACK OF POWER OR EXCESSIVE FUEL CONSUMPTION.

---

**EXCESSIVE OIL CONSUMPTION OR WHITE EXHAUST**

---

(Possible Cause)

(Check Procedure and Correction Method)

**FAULTY TURBOCHARGER OIL SEAL**

Check for oil leakage in exhaust system.

- Remove the turbine elbow from the turbocharger and check for excessive carbon deposits on the turbine wheel. Excessive carbon deposits would indicate a faulty turbocharger.

Check for oil leakage in intake air system.


- Check for plays in turbine shaft, and replace the turbocharger if necessary. (See page TC-12)

**Axial play: 0.13 mm (0.0051 in.) or less**

**Radial play: 0.18 mm (0.0071 in.) or less**

# TURBOCHARGER ELECTRICAL SYSTEM DIAGNOSIS (HZJ80)

## TROUBLESHOOTING OF TURBOCHARGER INDICATOR LIGHT AND WARNING LIGHT OPERATION



## TURBOCHARGER

### ON-VEHICLE INSPECTION OF TURBOCHARGER

#### 1. INSPECT INTAKE AIR SYSTEM

Check for leakage or clogging between the air cleaner and turbocharger inlet and between the turbocharger outlet and cylinder head.

- Clogged air cleaner .... Clean or replace the element
- Hoses collapsed or deformed .... Check each connection and repair
- Cracks in components .... Check and replace

#### 2. INSPECT EXHAUST SYSTEM

Check for leakage or clogging between the cylinder head and turbocharger inlet and between the turbocharger outlet and exhaust pipe.

- Deformed components .... Repair or replace
- Foreign material in passages .... Remove
- Leakage from components .... Repair or replace
- Cracks in components .... Check and replace

#### 3. CHECK TURBOCHARGING PRESSURE

- (a) Warm up engine.
- (b) Connect a 3-way union to the intake pipe pressure hose and install SST (turbocharger pressure gauge) to it.

SST 09992-00241

- (b) Press in the clutch pedal, then press the accelerator pedal down as far as it will go. Measure the turbocharging pressure at maximum speed (4,400 rpm).

**Standard pressure: 0.50-0.65 kg/cm<sup>2</sup>  
(7.1-9.2 psi, 49-64 kPa)**



If the pressure is less than specification, check the intake air and exhaust systems for leakage. If there is no leakage, replace the turbocharger assembly.

If the pressure is above specification, check if the actuator hose is disconnected or cracked. If not, replace the turbocharger assembly.


#### 4. INSPECT IMPELLER WHEEL ROTATION


- (a) Disconnect the air cleaner hose.
- (b) Grasp the edge of the impeller wheel and turn it. Check that it turns smoothly.

If it does not turn or if it turns with drag, replace the turbocharger assembly.



## COMPONENTS






## REMOVAL OF TURBOCHARGER

(See page TC-9)

### 1. DRAIN ENGINE COOLANT (See page CO-4)


### 2. REMOVE INTAKE PIPE

- (a) Disconnect the vacuum hose for the boost compensator.
- (b) Disconnect the air hose clamp bolt.
- (c) Remove the three bolts and intake pipe.




### 3. REMOVE EXHAUST MANIFOLD HEAT INSULATOR

Remove the five bolts and heat insulator.




### 4. DISCONNECT WATER BY-PASS HOSES




### 5. REMOVE TURBO HEAT INSULATOR

Remove the two bolt and heat insulator.




### 6. REMOVE TURBOCHARGER STAY


Remove the three bolts and turbocharger stay.

**7. REMOVE TURBO OIL PIPE**


- (a) Remove the union bolt and two gaskets holding the turbo oil pipe to the cylinder block.
- (b) Disconnect the turbo oil hose.
- (c) Remove the two nuts, turbo oil pipe and gasket.

**8. REMOVE TURBOCHARGER AND EXHAUST MANIFOLD ASSEMBLY**


Remove the twelve nuts, the turbocharger and exhaust manifold assembly and gaskets.

**9. SEPARATE TURBOCHARGER AND EXHAUST MANIFOLD**


Remove the four nuts, turbocharger and gasket.

**10. REMOVE NO.2 TURBO HEAT INSULATOR**

Remove the two bolts and No.2 turbo heat insulator.


**11. REMOVE NO.1 TURBO WATER PIPE**

Remove the two nuts, No.1 turbo water pipe and gasket.



## 12. REMOVE TURBINE OUTLET ELBOW

Remove the four nuts, turbine outlet elbow and gasket.




## INSPECTION OF TURBOCHARGER

### 1. INSPECT IMPELLER WHEEL ROTATION

Grasp the edge of the turbine wheel and turn it. Check that the impeller wheel turns smoothly.

If the impeller wheel does not turn or if it turns with a drag, replace the turbocharger assembly.




### 2. INSPECT AXIAL PLAY OF IMPELLER WHEEL

Insert a dial indicator into the exhaust side, hold the turbine wheel edge by hand and check the axial play.

**Axial play: 0.13 mm (0.0051 in.) or less**

If the axial play is not as specified, replace the turbocharger assembly.



### 3. INSPECT RADIAL PLAY OF TURBINE SHAFT


(a) From the oil outlet hole, insert the dial indicator through the hole in the spacer bearing and set it in the center of the turbine shaft.

(b) Moving the turbine shaft in a radial direction, measure the radial play of the shaft.

**Radial play: 0.18 mm (0.0071 in.) or less**

If the radial play is not as specified, replace the turbocharger assembly.






#### 4. INSPECT ACTUATOR OPERATION

- Disconnect the actuator hose.
- Using SST (turbocharger pressure gauge), apply approx.  $0.92 \text{ kg/cm}^2$  (13.1 psi, 90 kPa) of pressure to the actuator and check that the rod moves.

SST 09992-00241

If the rod does not move, replace the turbocharger assembly.


**NOTICE:** Never apply more than  $1.05 \text{ kg/cm}^2$  (14.9 psi, 103 kPa) of pressure to the actuator.



#### INSTALLATION OF TURBOCHARGER

(See page TC-9)


**NOTICE:** After replacing the turbocharger assembly, pour approx. 20 cc (1.2 cu in.) of new oil into the oil inlet and turn the impeller wheel by hand to splash oil on the bearing.



#### 1. INSTALL TURBINE OUTLET ELBOW

Install a new gasket and the turbine outlet elbow with the four nuts.


**Torque:** 530 kg-cm (38 ft-lb, 52 N-m)



#### 2. INSTALL NO.1 TURBO WATER PIPE

Install a new gasket and the water pipe with the two nuts.


**Torque:** 80 kg-cm (69 in.-lb, 7.8 N-m)



#### 3. INSTALL NO.2 TURBO HEAT INSULATOR

Install the No.2 turbo heat insulator with the two bolts.


**Torque:** 80 kg-cm (69 in.-lb, 7.8 N-m)



#### 4. ASSEMBLE TURBOCHARGER AND EXHAUST MANIFOLD

Install a new gasket and the turbocharger to the exhaust manifold with the four nuts.

**Torque: 530 kg-cm (38 ft-lb, 52 N-m)**





#### 5. INSTALL TURBOCHARGER AND EXHAUST MANIFOLD ASSEMBLY

(a) Install two new gaskets to the cylinder head.

(b) Install the turbocharger and exhaust manifold assembly with the twelve nuts.

**Torque: 400 kg-cm (29 ft-lb, 39 N-m)**

**HINT:** Apply 330 kg-cm (24 ft-lb, 32 N-m) of torque when performing additional tightening of loosed nuts.



#### 6. INSTALL TURBO OIL PIPE


(a) Install a new gasket and the turbo oil pipe with the two nuts.

**Torque: 185 kg-cm (13 ft-lb, 18 N-m)**

(b) Connect the turbo oil hose.

(c) Install two new gaskets and the union bolt of the turbo oil pipe.


**Torque: 250 kg-cm (18 ft-lb, 25 N-m)**



#### 7. INSTALL TURBOCHARGER STAY



Install the turbocharger stay with the three bolts.

**Torque: 1,200 kg-cm (87 ft-lb, 118 N-m)**

**8. INSTALL TURBOCHARGER HEAT INSULATOR**


Install the heat insulator with the two bolts.

**Torque: 185 kg-cm (13 ft-lb, 18 N·m)**

**9. CONNECT WATER BY-PASS HOSES****10. INSTALL EXHAUST MANIFOLD HEAT INSULATOR**

Install the heat insulator with the five bolts.

**Torque: 185 kg-cm (13 ft-lb, 18 N·m)**

**11. INSTALL INTAKE PIPE**

- (a) Connect the air hose and install a new gasket and the intake pipe with the three bolts.

**Torque: 200 kg-cm (14 ft-lb, 20 N·m)**

- (b) Connect boost compensator vacuum hose.


**12. FILL ENGINE WITH COOLANT (See page CO-5)****13. START ENGINE AND CHECK FOR LEAKS****14. CHECK ENGINE OIL LEVEL**

# FUEL SYSTEM

NOTE: For troubleshooting procedures, refer to TROUBLESHOOTING (EM Section).

	Page
DESCRIPTION.....	FU-2
REPLACEMENT OF FUEL FILTER.....	FU-4
FUEL HEATER SYSTEM.....	FU-6
INJECTION NOZZLES (1PZ and 1 HZ).....	FU-9
INJECTION NOZZLES (1HD-T).....	FU-16
INJECTION PUMP.....	FU-27
POWER CONTROL SYSTEM (PCS) (HDB30(w/ M/T) only).....	FU-95

## DESCRIPTION




FU2893

## FUEL SYSTEM

Fuel is drawn up from the fuel tank through the fuel filter (sedimenter) by the feed pump built into the injection pump. The fuel drawn up is then sent into the pump housing. Fuel compressed in the pump housing is distributed to the injection nozzles according to the injection order, and injected at high pressure into the combustion chamber. Excess fuel in the pump housing flows through the overflow valve and along the overflow pipe and returns to the fuel tank. The fuel cycle provides both cooling and lubrication for the pump. The cycling of fuel through the pump chamber warms the fuel so that it is prevented from becoming wax-like at cold temperatures.

## Injection Pump (VE Pump)



## OPERATION

- The centrifugal force type feed pump takes up a fixed volume of fuel with each turn. The fuel expulsion pressure from the feed pump is controlled by operation of the pressure regulator valve.
- Fuel is sent from the outlet side of the feed pump, through the hole in the upper part of the feed pump cover and into the pump body.
- The pump plunger also rotates as it moves up and down. After the fuel is drawn in, it is distributed under pressure to the delivery valve of each cylinder according to the injection order.
- The centrifugal force type all speed governor installed in the upper part of the injection pump moves the spill ring obstructing the plunger spill port and controls the fuel injection volume.
- The hydraulic type timer installed in the lower part of the injection pump is operated by the fuel pressure of the pump housing, and movement of the roller ring by the timer advances the injection angle and controls the injection timing.
- The fuel cut solenoid valve is connected to the starter switch IG circuit, and when the starter switch is turned to OFF, the current is cut off, the solenoid is de-energized, fuel is cut off and the engine stops.
- High Altitude Compensation (HAC) Device  
Due to the decrease in atmospheric pressure at high altitudes, the air fuel ratio becomes more dense and the smoke density increases. To prevent this, the device automatically reduces the fuel injection volume for full loads in response to the altitude.
- Boost Compensator with turbocharger  
The boost compensator is installed on the upper part of the governor of the injection pump. Turbocharged air pressure moves the diaphragm and push rod up and down, this movement is conveyed to the spill ring and the fuel injection volume increases according to the degree of movement.

## REPLACEMENT OF FUEL FILTER

### 1. DISCONNECT FUEL FILTER WARNING SWITCH CONNECTOR

### 2. DRAIN FUEL FROM FUEL FILTER


- (a) Connect a vinyl hose to the drain cock, and insert the other end of the vinyl hose in a container.
- (b) Loosen the drain plug, and drain the fuel.

### 3. REPLACE FUEL FILTER

#### A. Remove fuel filter

Using SST, remove the fuel filter.


SST 09228-64010



#### B. Remove fuel filter warning switch from fuel filter


Using pliers, remove the warning switch and O-ring.

**NOTICE:** Be careful not to damage the warning switch.





#### C. Install fuel filter warning switch to new fuel filter

- (a) Install a new O-ring to the warning switch.
- (b) Apply fuel to the O-ring of the warning switch.




- (c) Install the warning switch to a new fuel filter by hand.




**D. Install new fuel filter**

- (a) Check and clean the fuel filter installation surface.
- (b) Apply fuel to the gasket of a new fuel filter.



- (c) Lightly screw the fuel filter into place, and tighten it until the gasket comes into contact with the seat.
- (d) Tighten it additional 3/4 turn by hand.

**4. FILL FUEL FILTER WITH FUEL**


Operate the hand pump until you feel more resistance.

**5. CONNECT FUEL FILTER WARNING SWITCH CONNECTOR****6. START ENGINE AND CHECK FOR FUEL LEAKS**





## FUEL HEATER SYSTEM SYSTEM CIRCUIT

**PZJ70, 73, 75, HZJ70, 73, 75, HZB30 and HDB30**



**HZJ80 and HDJ80**





## INSPECTION OF COMPONENTS


### Fuel Heater

#### INSPECT FUEL HEATER

- Apply a vacuum of  $350 \pm 50$  mmHg ( $13.78 \pm 1.97$  in.Hg,  $46.7 \pm 6.7$  kPa) or more to the vacuum switch port.
- Using an ohmmeter, measure the resistance between terminal 1 and the switch body.

**Resistance: 0.5-2.0 Ω at 20°C (68°F)**

If the resistance is not as specified, replace the fuel heater and vacuum switch assembly.




### Vacuum Switch

#### 1. INSPECT SWITCH CONTINUITY

Using an ohmmeter, check that there is no continuity between terminal 1 and the switch body.


If continuity is not as specified, replace the fuel heater and vacuum switch assembly.



#### 2. INSPECT SWITCH OPERATION


- Apply a vacuum of  $350 \pm 50$  mmHg ( $13.78 \pm 1.97$  in.Hg,  $46.7 \pm 6.7$  kPa) or more to the vacuum switch port.
- Using an ohmmeter, check that there is continuity between terminal 1 and the switch body.

If operation is not as specified, replace the fuel heater and vacuum switch assembly.



### Fuel Heater Relay (HZJ80 and HDJ80 only)


LOCATION: In the engine compartment relay box.



#### 1. INSPECT RELAY CONTINUITY

- (a) Using an ohmmeter, check that there is continuity between terminals 1 and 3.
- (c) Check that there is no continuity between terminals 2 and 4.

If continuity is not as specified, replace the relay.





#### 2. INSPECT RELAY OPERATION

- (b) Apply battery voltage across terminals 1 and 3.
- (c) Using an ohmmeter, check that there is continuity between terminals 2 and 4.

If operation is not as specified, replace the relay.

# INJECTION NOZZLES (1 PZ and 1 HZ)


## REMOVAL OF INJECTION NOZZLES




### 1. REMOVE INTAKE PIPE (See step 6 on page EM-34)

### 2. REMOVE INJECTION PIPES


- Loosen the union nuts of the injection pipes from the injection nozzles.
- Loosen the union nuts of the injection pipes from the injection pump.
- Remove the three clamps and injection pipes.





### 3. REMOVE NOZZLE LEAKAGE PIPE


- (a) Disconnect the fuel hose from the nozzle leakage pipe.
- (b) Remove the nuts, leakage pipe and gaskets.



### 4. REMOVE INJECTION NOZZLES

Using SST, remove the injection nozzles, seats and gaskets.  
SST 09268-64010

HINT: Arrange the injection nozzles in correct order.



## TEST OF INJECTION NOZZLES

### 1. INJECTION PRESSURE TEST



- (a) Install the injection nozzle to the injection nozzle hand tester and bleed air from the union nut.

**CAUTION:** Do not place your finger over the nozzle injection hole.

- (b) Pump the tester handle a few times as fast as possible to discharge the carbon from the injection hole.
- (c) Pump the tester handle slowly and observe the pressure gauge.
- (d) Read the pressure gauge just as the injection pressure begins to drop.

**Opening pressure:**

<b>New nozzle</b>	145 -155 kg/cm <sup>2</sup> (2,062-2,205 psi) (14,220-15,200 kPa)
<b>Reused nozzle</b>	135- 155 kg/cm <sup>2</sup> (1,920-2,205 psi) (13,239-15,200 kPa)



HINT: Proper nozzle operation can be determined by a swishing sound.

If the opening pressure is not as specified, disassemble the nozzle holder and change the adjusting shim on the top of the pressure spring. (See page FU-13).

**Adjusted opening pressure: 135- 155 kg/cm<sup>2</sup>  
(1,920-2,205 psi)  
(13,239-15,200 kPa)**

Adjusting shim thickness			mm (in.)
0.900 (0.0354)	1.275 (0.0502)	1.650 (0.0650)	
0.925 (0.0364)	1.300 (0.0512)	1.675 (0.0659)	
0.950 (0.0374)	1.325 (0.0522)	1.700 (0.0669)	
0.975 (0.0384)	1.350 (0.0531)	1.725 (0.0679)	
1.000 (0.0394)	1.375 (0.0541)	1.750 (0.0689)	
1.025 (0.0404)	1.400 (0.0551)	1.775 (0.0699)	
1.050 (0.0413)	1.425 (0.0561)	1.800 (0.0709)	
1.075 (0.0423)	1.450 (0.0571)	1.825 (0.0719)	
1.100 (0.0433)	1.475 (0.0581)	1.850 (0.0728)	
1.125 (0.0443)	1.500 (0.0591)	1.875 (0.0738)	
1.150 (0.0453)	1.525 (0.0600)	1.900 (0.0748)	
1.175 (0.0463)	1.550 (0.0610)	1.925 (0.0758)	
1.200 (0.0472)	1.575 (0.0620)	1.950 (0.0768)	
1.225 (0.0482)	1.600 (0.0630)		
1.250 (0.0492)	1.625 (0.0640)		

HINT:



- Varying the adjusting shim thickness by 0.025 mm (0.0010 in.) changes the injection pressure by about 4.5 kg/cm<sup>2</sup> (64 psi, 441 kPa) (1PZ).
- Varying the adjusting shim thickness by 0.025 mm (0.0010 in.) changes the injection pressure by about 3.5 kg/cm<sup>2</sup> (50 psi, 343 kPa) (1HZ).
- Only one adjusting shim should be used.

(f) There should be no dripping after injection.

## 2. LEAKAGE TEST

While maintaining pressure at about 10-20 kg/cm<sup>2</sup> (142-284 psi, 981 -1,961 kPa) below opening pressure (adjust by tester handle), check that there is no dripping for 10 seconds from the injection hole or around the retaining nut.

If the nozzle drips within 10 seconds, replace or clean and overhaul the nozzle assembly.




## 3. SPRAY PATTERN TEST

- The injection nozzle should shudder at a certain pumping speed between 15 - 60 times (old nozzle) or 30 - 60 times (new nozzle) per minute.
- Check the spray pattern during shuddering.


If the spray pattern is not correct during shuddering, the nozzle must be replaced or cleaned.

## COMPONENTS



kg-cm (ft-lb, N·m) : Specified torque

FU2714



FU2909


## DISASSEMBLY OF INJECTION NOZZLES

## DISASSEMBLE INJECTION NOZZLES

- (a) Using SST, remove the nozzle holder retaining nut.  
SST 09268-64010

**NOTICE:** When disassembling the nozzle, be careful not to drop the inner parts.

- (b) Remove the pressure spring, shim, pressure pin, distance piece and the nozzle assembly.




FU0559

## CLEANING AND INSPECTION OF INJECTION NOZZLES


## 1. NOZZLE CLEANING

- (a) To wash the nozzles. Use a wooden stick and brass brush. Wash them in clean diesel fuel.


**HINT:** Do not touch the nozzle mating surfaces with your fingers.



- (b) Using a wooden stick, remove the carbon adhering to the nozzle needle tip.




- (c) Using a brass brush, remove the carbon from the exterior of the nozzle body (except lapped surface).



- (d) Check the seat of the nozzle body for burns or corrosion.

- (e) Check the nozzle needle tip for damage or corrosion.  
If any of these conditions are present, replace the nozzle assembly.




## 2. INSPECT NOZZLE ASSEMBLY

- (a) Wash the nozzle in clean diesel fuel.

HINT: Do not touch the nozzle mating surfaces with your fingers.


- (b) Tilt the nozzle body about 60 degrees and pull the needle out about one third of its length.



- (c) When released, the needle should sink down into the body vent smoothly by its own weight.

- (d) Repeat this test, rotating the needle slightly each time.  
If the needle does not sink freely, replace the nozzle assembly.





## ASSEMBLY OF INJECTION NOZZLES

(See page FU-12)

### 1. ASSEMBLE INJECTION NOZZLE HOLDERS


- Assemble the nozzle holder retaining nut, the nozzle assembly, distance piece, pressure pin, pressure spring, adjusting shim and nozzle holder body, and finger tighten the retaining nut.
- Using SST, tighten the retaining nut.

SST 09268-64010

**Torque:** 375 kg-cm (27 ft-lb, 37 N·m)

**NOTICE:** Over torquing could cause nozzle deformation and needle adhesion or other defects.

### 2. PERFORM PRESSURE AND SPRAY PATTERN TEST (See pages FU-10, 11)



## INSTALLATION OF INJECTION NOZZLES

(See page FU-9)

### 1. INSTALL INJECTION NOZZLES


- Place new gaskets and the nozzle seats into the injection nozzle holes of the cylinder head.
- Using SST, install the injection nozzles.

SST 09268-64010

**Torque:** 650 kg-cm (47 ft-lb, 64 N·m)

**NOTICE:**

- Over torquing could cause nozzle deformation and needle adhesion or other defects.
- When installing the injection nozzle, never torque the nozzle holder body. Torque the retaining nut section.




### 2. INSTALL NOZZLE LEAKAGE PIPE

- Install new gaskets and the leakage pipe with the nuts.


**Torque:** 300 kg-cm (22 ft-lb, 29 N·m)

- Connect the fuel hose to the return pipe.

**3. INSTALL INJECTION PIPES**

- (a) Place the two clamps on the intake manifold.
- (b) Connect the injection pipes to injection nozzle.


**Torque: 150 kg-cm (11 ft-lb, 15 N·m)**



- (c) Connect the injection pipes to injection pump.

**Torque: 150 kg-cm (11 ft-lb, 15 N·m)**

- (d) Secure the injection pipes with clamps and bolts.


**4. INSTALL INTAKE PIPE**

(See step 3 on page EM-38)

**5. START ENGINE AND CHECK FOR FUEL LEAKS**

## INJECTION NOZZLES (1HD-T)


### REMOVAL OF INJECTION NOZZLES



kg-cm (ft-lb, N·m) : Specified torque

◆ Non-reusable part


FU2845



#### 1. REMOVE INTAKE PIPE (See step 6 on page EM-34)


#### 2. DISCONNECT INJECTION PIPES

Loosen the union nuts of the six injection pipes from the six injection nozzles.



#### 3. REMOVE NOZZLE LEAKAGE PIPE



- Disconnect the fuel hose from the nozzle leakage pipe.
- Remove the six hollow bolts, leakage pipe and twelve gaskets.



#### 4. REMOVE INJECTION NOZZLES

- (a) Remove the bolt, washer, nozzle holder clamp, injection nozzle and seat.
- (b) Remove the O-ring from the injection nozzle.

HINT: Arrange the injection nozzles in correct order.



#### TEST OF INJECTION NOZZLES

##### 1. LEAKAGE TEST


While maintaining pressure at about 10-20 kg/cm<sup>2</sup> (142-284 psi, 981-1,961 kPa) below No.1 opening pressure (adjust by tester handle), check that there is no dripping for 10 seconds from the injection hole or around the retaining nut.

If the nozzle drips within 10 seconds, replace or clean and overhaul the nozzle assembly.



##### 2. SPRAY PATTERN TEST

- (a) The injection nozzle should shudder at a certain pumping speed between 15 - 60 times (old nozzle) or 30-60 times (new nozzle) per minute.
- (b) Check the spray pattern during shuddering.

If the spray pattern is not correct during shuddering, the nozzle must be clean or replaced.



## COMPONENTS



## DISASSEMBLY OF INJECTION NOZZLES

### DISASSEMBLE INJECTION NOZZLES

- Remove the nozzle holder retaining nut.

**NOTICE:** When disassembling the nozzle, be careful not to drop the inner parts.


- Remove the nozzle sub-assembly and distance piece, straight pins, No.1 pressure pin, No.1 pressure spring, adjusting shim, capsule sub-assembly and adjusting shim.


## CLEANING AND INSPECTION OF INJECTION NOZZLES

### 1. NOZZLE CLEANING


- To wash the nozzles. Use a wooden stick and brass brush. Wash them in clean diesel fuel.

**HINT:** Do not touch the nozzle mating surfaces with your fingers.






- (b) Using a wooden stick, remove the carbon adhering to the nozzle needle tip.




- (c) Using a brass brush, remove the carbon from the exterior of the nozzle body (except lapped surface).



- (d) Check the seat of the nozzle body for burns or corrosion.

- (e) Check the nozzle needle tip for damage or corrosion. If any of these conditions are present, replace the nozzle assembly.




## 2. INSPECT NOZZLE ASSEMBLY

- (a) Wash the nozzle in clean diesel fuel.

HINT: Do not touch the nozzle mating surfaces with your fingers.

- (b) Tilt the nozzle body about 60 degrees and pull the needle out about one third of its length.



- (c) When released, the needle should sink down into the body vent smoothly by its own weight.

- (d) Repeat this test, rotating the needle slightly each time. If the needle does not sink freely, replace the nozzle assembly.

## ASSEMBLY AND ADJUSTMENT OF INJECTION NOZZLES

(See page FU-18)

### 1. ADJUST PRE-LIFT

**NOTICE:** Pre-lift adjustment requires great precision, so when performing this operation, make sure everything is clean and that no foreign substances are trapped.

- (a) Install the SST to the dial indicator so that the protrusion shown in the illustration is 2.0 mm (0.079 in.) or less.

SST 09268-17010

- (b) Set the dial indicator scale to 0 mm (0 in.) on top of SST or surface plate.

SST 09268-17010





- (c) Place the nozzle sub-assembly, distance piece, straight pins and No.1 pressure pin on the SST as shown in the illustration.


SST 09268-17010

- (d) Install SST holes to the straight pins and measure dimension 11.


SST 09268-17010

**Dimension £2 (Reference): 4.70 mm (0.1850 in.)**







- (e) Install SST to the dial indicator so that the protrusion shown in the illustration is 7.0 mm (0.276 in.) or less.  
SST 09268-17010



- (f) Set the dial indicator scale to 0 mm (0 in.) on top of SST or surface plate.  
SST 09268-17010



- (g) Place the adjusting shim, the capsule sub-assembly and straight pins on the nozzle holder body.



- (h) Install SST holes to the straight pins and measure dimension f1.  
SST 09268-17010  
**Dimension f1 (Reference): 4.79 mm (0.1886 in.)**



(i) Subtract the dimension £2 from the dimension £1.

**Pre-lift: 0.08 - 0.10 mm (0.0031 - 0.0039 in.)**

If the pre-lift dimension is not as specified, change the adjusting shim on the top of the capsule sub-assembly.

Adjusting shim thickness			mm (in.)
0.700 (0.0276)	1.310 (0.0516)	1.520 (0.0598)	
0.750 (0.0295)	1.320 (0.0520)	1.530 (0.0602)	
0.800 (0.0315)	1.330 (0.0524)	1.540 (0.0606)	
0.850 (0.0335)	1.340 (0.0528)	1.550 (0.0610)	
0.900 (0.0354)	1.350 (0.0531)	1.560 (0.0614)	
0.950 (0.0374)	1.360 (0.0535)	1.570 (0.0618)	
0.975 (0.0384)	1.370 (0.0539)	1.580 (0.0622)	
1.000 (0.0394)	1.380 (0.0543)	1.590 (0.0626)	
1.025 (0.0404)	1.390 (0.0547)	1.600 (0.0630)	
1.050 (0.0413)	1.400 (0.0551)	1.610 (0.0634)	
1.075 (0.0423)	1.410 (0.0555)	1.620 (0.0638)	
1.100 (0.0433)	1.420 (0.0559)	1.630 (0.0641)	
1.125 (0.0443)	1.430 (0.0563)	1.640 (0.0646)	
1.150 (0.0453)	1.440 (0.0567)	1.650 (0.0650)	
1.175 (0.0463)	1.450 (0.0571)	1.660 (0.0654)	
1.200 (0.0472)	1.460 (0.0575)	1.670 (0.0657)	
1.225 (0.0482)	1.470 (0.0579)	1.680 (0.0661)	
1.250 (0.0492)	1.480 (0.0583)	1.690 (0.0665)	
1.280 (0.0504)	1.490 (0.0587)	1.700 (0.0669)	
1.290 (0.0508)	1.500 (0.0591)	1.750 (0.0689)	
1.300 (0.0512)	1.510 (0.0594)	1.800 (0.0709)	

**HINT:** If the shim is made thicker, the pre-lift is decreased.

## 2. CHECK NO.2 OPENING PRESSURE

(a) Loosen by one or two turns the plug screw of the capsule sub-assembly with SST.



SST 09268-17010


**HINT:** When the plug screw is loosened by one or two turns, the pre-lift from installation in the nozzle holder becomes 0 mm (0 in.).

(b) Assemble the following parts:


- (1) Nozzle holder body
- (2) Adjusting shim selected in step 1 above
- (3) Capsule sub-assembly in the condition from step 2 (a)
- (4) No.1 pressure pin
- (5) Distance piece
- (6) Straight pins
- (7) Nozzle sub-assembly
- (8) Retaining nut

**NOTICE:** Do not assemble the No.1 pressure spring and the adjusting shim for adjustment of the No.1 opening pressure.






HINT: Align the holes of the nozzle body, distance piece and nozzle holder body.



- (c) Using a 14 mm deep socket wrench, torque the retaining nut.

**Torque: 350 kg-cm (25 ft-lb, 34 N·m)**


**NOTICE: Over torquing could cause nozzle deformation and needle adhesion or other defects.**



- (d) Install the injection nozzle to the injection nozzle hand tester and bleed air from the union nut.

**CAUTION: Do not place your finger over the nozzle injection hole.**

- (e) Pump the tester handle a few times as fast as possible to discharge the carbon from the injection hole.



- (f) Pump the tester handle slowly and observe the pressure gauge.
- (g) Read the pressure gauge just as the injection pressure begins to drop.


**No.2 opening pressure (Inspection pressure):**  
**132-138 kg/cm<sup>2</sup>**  
**(1,877-1,963 psi, 12,945-13,533 kPa)**


HINT: Proper nozzle operation can be determined by a swishing sound.

If the opening pressure is not as specified, replace the capsule sub-assembly.

HINT: The No.2 opening pressure is already adjusted for the new capsule sub-assembly.

- (h) There should be no dripping after injection.






- (i) After checking the No.2 opening pressure, remove the capsule sub-assembly and tighten the plug screw with SST.

SST 09268-17010

**Torque: 25 kg-cm (21 in.-lb, 2.5 N-m)**


### 3. ADJUST NO.1 OPENING PRESSURE

- (a) Assemble the nozzle holder body, adjusting shim selected in step 1, the capsule sub-assembly, adjusting shim for adjustment of No.1 opening pressure, No.1 pressure spring, No.1 pressure pin, distance piece, straight pins and the nozzle sub-assembly, and finger tighten the retaining nut.



#### HINT:


- Align the holes of the nozzle body, distance piece and nozzle holder body.
- When the thickness of the originally used adjusting shim is not known, use a shim 1.5 mm (0.59 in.) thick instead.



- (b) Using a 14 mm deep socket wrench, torque the retaining nut.


**Torque: 350 kg-cm (25 ft-lb, 34 N-m)**

**NOTICE: Over torquing could cause nozzle deformation and needle adhesion or other defects.**



- (c) Install the injection nozzle to the injection nozzle hand tester and bleed air from the union nut.

**CAUTION: Do not place your finger over the nozzle injection hole.**



- (d) Pump the tester handle slowly and observe the pressure gauge.
- (e) Read the pressure gauge just as the injection pressure begins to drop.

**No.1 opening pressure: 180-190 kg/cm<sup>2</sup>  
(2,560-2,702 psi)  
(17,652-18,633 kPa)**

**HINT:** Proper nozzle operation can be determined by a swishing sound.

If the opening pressure is not as specified, disassemble the nozzle and change the adjusting shim on the top of the No.1 pressure spring.


Adjusting shim thickness			mm (in.)
0.700 (0.0276)	1.310 (0.0516)	1.520 (0.0598)	
0.750 (0.0295)	1.320 (0.0520)	1.530 (0.0602)	
0.800 (0.0315)	1.330 (0.0524)	1.540 (0.0606)	
0.850 (0.0335)	1.340 (0.0528)	1.550 (0.0610)	
0.900 (0.0354)	1.350 (0.0531)	1.560 (0.0614)	
0.950 (0.0374)	1.360 (0.0535)	1.570 (0.0618)	
0.975 (0.0384)	1.370 (0.0539)	1.580 (0.0622)	
1.000 (0.0394)	1.380 (0.0543)	1.590 (0.0626)	
1.025 (0.0404)	1.390 (0.0547)	1.600 (0.0630)	
1.050 (0.0413)	1.400 (0.0551)	1.610 (0.0634)	
1.075 (0.0423)	1.410 (0.0555)	1.620 (0.0638)	
1.100 (0.0433)	1.420 (0.0559)	1.630 (0.0641)	
1.125 (0.0443)	1.430 (0.0563)	1.640 (0.0646)	
1.150 (0.0453)	1.440 (0.0567)	1.650 (0.0650)	
1.175 (0.0463)	1.450 (0.0571)	1.660 (0.0654)	
1.200 (0.0472)	1.460 (0.0575)	1.670 (0.0657)	
1.225 (0.0482)	1.470 (0.0579)	1.680 (0.0661)	
1.250 (0.0492)	1.480 (0.0583)	1.690 (0.0665)	
1.280 (0.0504)	1.490 (0.0587)	1.700 (0.0669)	
1.290 (0.0508)	1.500 (0.0591)	1.750 (0.0689)	
1.300 (0.0512)	1.510 (0.0594)	1.800 (0.0709)	


**HINT:**

- Varying the adjusting shim thickness by 0.01 mm (0.0004 in.) changes the injection pressure by about 1.5 kg/cm<sup>2</sup> (21 psi, 147 kPa).

- Only one adjusting shim should be used.

- (f) There should be no dripping after injection.





## INSTALLATION OF INJECTION NOZZLES

(See page FU-17)


### 1. INSTALL INJECTION NOZZLES

- (a) Install a new O-ring to the injection nozzle.

- (b) Install new nozzle seats into the injection nozzle hole of the cylinder head.

- (c) Install the injection nozzles with the washer, nozzle holder clamp and bolt.

**Torque: 400 kg-cm (29 ft-lb, 39 N-m)**




### 2. INSTALL NOZZLE LEAKAGE PIPE

- (a) Install new gaskets and the leakage pipe with the hollow bolts.

**Torque: 125 kg-cm (9 ft-lb, 12 N-m)**


- (b) Connect the fuel hose to the return pipe.



### 3. CONNECT INJECTION PIPES

Connect the injection pipes to injection nozzle.

**Torque: 250 kg-cm (18 ft-lb, 25 N-m)**




### 4. INSTALL INTAKE PIPE

(See step 3 on page EM-38)


### 5. START ENGINE AND CHECK FOR FUEL LEAKS

# INJECTION PUMP


## REMOVAL OF INJECTION PUMP




1. (w/ACSD)  
DRAIN COOLANT (See page CO-5)
2. REMOVE TIMING BELT  
(See steps 1 to 3 on pages EM-33 to 34)
3. REMOVE NO.2 CAMSHAFT TIMING PULLEY  
(See step 5 on pages EM-34)
4. DISCONNECT ACCELERATOR CONNECTING ROD
5. (A/T)  
DISCONNECT THROTTLE CABLE
6. (w/ A/C)  
DISCONNECT A/C IDLE-UP VACUUM HOSE
7. (w/ ACSD)  
DISCONNECT WATER BY-PASS HOSES FROM THERMO WAX
8. DISCONNECT INJECTION PUMP CONNECTOR
9. DISCONNECT FUEL HOSES FROM INJECTION PUMP
10. (1HD-T)  
DISCONNECT BOOST COMPENSATOR HOSE
11. (w/PCS)  
DISCONNECT PCS VACUUM HOSE
12. (w/BACS)  
DISCONNECT BACS VACUUM HOSE
13. REMOVE INJECTION PIPES  
(See step 2 on page FU-9)



14. REMOVE INJECTION PUMP
  - (a) Using SST, remove the injection pump drive gear set nut.  
SST 09330-00021




- (b) Remove the bolt holding the injection pump to pump stay.



(c) Before removing the injection pump, check if the period lines are aligned.

If not, place new matchmarks for reinstallation.

(d) Remove the two nuts holding the injection pump to the timing gear case.



(e) Using SST, remove the injection pump.

SST 09213-60017 (09213-00020, 09213-00030, 09213-00060) and 09950-20017


**NOTICE:**

- Tighten the two bolts more than 8 mm (0.31 in.).
  - Set SST so that it is balanced.
  - Do not hold or carry the injection pump by the adjusting lever.
  - Do not put the injection pump (with HAC, or for the 1 HD-T) at an angle more than 45° from the horizontal.
- (f) Remove the cylinder block insulator (1 PZ and 1 HZ (M/T) for Europe).
- (g) Remove the O-ring from the injection pump.




## COMPONENTS


## 1PZ (w/o HAC) and 1HZ (w/o HAC)



## 1PZ (w/ HAC) and 1HZ (w/ HAC)




## 1HD-T



kg-cm (ft-lb, N·m) : Specified torque

◆ Non-reusable part


## COMPONENTS (Cont'd)




kg-cm (ft-lb, N·m) : Specified torque

◆ Non-reusable part

## COMPONENTS (Cont'd)






## DISASSEMBLY OF INJECTION PUMP

(See pages FU-30, 31 and 32)


1. **MOUNT PUMP ASSEMBLY TO SST (STAND)**  
SST 09241 -76022 and 09245-54010
2. **REMOVE SET KEY OF DRIVE PULLEY FROM DRIVE SHAFT**
3. **(w/ A/C)**  
**REMOVE IDLE-UP ACTUATOR**
4. **REMOVE TWO FUEL PIPES**

Place the matchmarks on the fuel inlet pipe and governor cover.




5. **(w/ ACSD)**  
**REMOVE IDLE-UP LEVER**

Using a 5 mm hexagon wrench, remove the three bolts and idle-up lever.





6. **(w/ ACSD)**  
**REMOVE THERMO WAX**

- (a) Using a screwdriver, turn the cold starting lever counterclockwise approx. 20°.
- (b) Put a metal plate (thickness of 3.5-7.5 mm) (0.138-0.295 in.) between the cold starting lever and thermo wax plunger.




- (c) Using a 5 mm hexagon wrench, remove the two bolts, thermo wax and O-ring.




**7. (w/ PCS)****REMOVE PCS ACTUATOR**


- (a) Remove the PCS adjusting screw.
- (b) Remove the clip.




- (c) Using a 5 mm hexagon wrench, remove the two bolts and PCS actuator assembly.

**8. (w/ PCS)****REMOVE NO.1 PCS LEVER**


Remove the nut and No.1 PCS lever.

**9. (w/ Dash Pot)****REMOVE DASH POT**


Remove the dash pot and gasket.

**10. REMOVE FUEL CUT SOLENOID**

- (a) Disconnect the lead wire connector from the bracket.
- (b) Disconnect the dust cover from the fuel cut solenoid.
- (c) Remove the nut, lead wire and dust cover.




- (d) Remove the fuel cut solenoid, O-ring, spring, valve, strainer and wave washer.




**11. (w/TACHOMETER)  
REMOVE PICKUP SENSOR**

Remove the pickup sensor and O-ring.




**12. REMOVE ADJUSTING LEVER**

- (a) Place the matchmarks on adjusting lever and shaft.




- (b) Remove the nut, return spring guide, adjusting lever and return spring.




**13. REMOVE GOVERNOR COVER**

- (a) (w/HAC and 1HD-T)  
Remove the idle speed adjusting screw.
- (b) Using a 5 mm hexagon wrench, remove the four bolts.




- (c) Disconnect the speed control spring from the spring seat, and remove the spring seat, damper spring, speed control spring, the governor cover and adjusting lever shaft assembly and gasket.



#### 14. REMOVE GOVERNOR ADJUSTING LEVER SHAFT FROM GOVERNOR COVER

Remove the following parts from the governor cover.


- (1) Adjusting lever shaft, O-ring and washer assembly
- (2) O-ring
- (3) Washer



#### 15. (1PZ(w/HAC) and 1HZ(w/HAC)) DISASSEMBLE HIGH ALTITUDE COMPENSATOR


##### A. Remove lever control spring

Remove the bolt, gasket and lever control spring.



##### B. Remove pneumatic bellows


- (a) Using a 5 mm hexagon wrench, remove the four bolts.



- (b) Remove the following parts:
- (1) Pneumatic bellows cover
  - (2) Gasket
  - (3) Shims


**NOTICE:** Note the number of the shims.

- (4) Pneumatic bellows
- (5) Two rubber caps
- (6) Push rod
- (7) Pneumatic bellows spring




### C. Remove control lever

- (a) Using a 4 mm hexagon wrench, remove the two bolts and gaskets.




- (b) Using a small screwdriver, push out the support pin and remove the control lever.



- (c) Using needle nose pliers, remove the connecting pin.

**NOTICE:** Be careful not to damage the connecting. Tape the tip of the pliers.






## 16. (1HD-T) DISASSEMBLE BOOST COMPENSATOR

### A. Remove lever control spring

Remove the bolt, gasket and lever control spring.




### B. Remove boost compensator diaphragm


(a) Using a 5 mm hexagon wrench, remove the four bolts.

(b) Remove the following parts:

- (1) Diaphragm cover
- (2) Diaphragm
- (3) Spring
- (4) Boost compensator shim





### C. Remove guide bushing




### D. Remove control lever

(a) Using a 4 mm hexagon wrench, remove the two bolts and gaskets.






- (b) Using a small screwdriver, push out the support pin and remove the control lever.



- (c) Using needle nose pliers, remove the connecting pin.


**NOTICE:** Be careful not to damage the connecting pin. Tape the tip of the pliers.



#### E. Remove ISb2 PCS lever

Remove the following parts from the governor cover.

- (1) No.2 lever, O-ring and washer assembly
- (2) O-ring
- (3) Washer




#### F. Remove No.2 overflow screw

Remove the cover and No.2 overflow screw.

### 17. CHECK FLYWEIGHT HOLDER THRUST CLEARANCE (See step 20 on page FU-58)

Thrust clearance: 0.15 - 0.35 mm  
(0.0059-0.0138 in.)



## 18. REMOVE GOVERNOR SHAFT AND FLYWEIGHT HOLDER

- (a) Remove the governor shaft lock nut by turning it clockwise.

**NOTICE:** The governor shaft and lock nut have LH threads.



- (b) Using a 5 mm hexagon wrench, remove the governor shaft clockwise, and remove the following part:

- (1) Flyweight holder assembly
- (2) No.1 flyweight washer
- (3) Governor gear adjusting washer

**HINT:** Be careful not to drop the two washers into the pump housing.


- (c) Remove the following parts from the flyweight holder.

- (1) Governor sleeve
- (2) No.2 flyweight washer
- (3) Four flyweights




## 19. REMOVE INJECTION PUMP STAY


Using a 5 mm hexagon wrench, remove the three bolts and stay.



## 20. REMOVE DISTRIBUTIVE HEAD PLUG

Using SST, remove the distributive head plug.  
SST 09260-54012 (09262-54010)






## 21. REMOVE DELIVERY VALVE HOLDERS

- (a) Using SST, remove the delivery valve holders, springs and spring seats.



SST 09260-5401 2 (09269-54020)

- (b) Remove the delivery valves and gaskets.




**NOTICE:** Do not touch the sliding surfaces of the delivery valve with your hand.


**HINT:** Arrange the delivery valves, springs, spring seats and holders in order.



## 22. REMOVE DISTRIBUTIVE HEAD


- (a) Using a 5 mm hexagon wrench, remove the four bolts.





(b) Remove the distributive head and following parts:

- (1) Two lever support springs
- (2) Two plunger spring guides
- (3) Two plunger spring shims
- (4) Two upper spring seats
- (5) Two plunger springs





### 23. REMOVE PUMP PLUNGER

Using SST, remove the pump plunger and plunger adjusting shim together with the following parts:

- (1) Spill ring
- (2) Lower spring seat
- (3) Upper plunger plate
- (4) Lower plunger plate

SST 09260-54012 (09269-54030)

**NOTICE:** Do not touch the sliding surfaces of the pump plunger with your hand.



### 24. REMOVE GOVERNOR LINK


Using SST, remove the two support bolts, gaskets and governor link.

SST 09260-54012 (09269-54040)




### 25. REMOVE FACE CAMPLATE AND COUPLING


Remove the face camplate, spring and coupling.

**26. REMOVE ROLLER RING AND DRIVE SHAFT**

(a) Remove the timer clip and stopper pin.



(b) Push the slide pin toward inside.




(c) (1PZ)


Push the drive shaft, and remove the roller ring, three rollers and shims assembly.


(1 HZ and 1HD-T)

Push the drive shaft, and remove the roller ring, four rollers and shims assembly.


**NOTICE:**

- Be careful not to drop the rollers.
- Do not alter the position or assembly of the rollers.






- (d) Remove the drive shaft, governor drive gear, two joint rubbers assembly, set key and drive shaft washer.




- (e) Remove the drive gear and two joint rubbers from the drive shaft.




## 27. REMOVE TIMER


- (a) Using a 5 mm hexagon wrench, remove the four bolts.



- (b) Remove the following parts:
- (1) LH timer cover, timer adjusting screw and nut assembly
  - (2) Spring
  - (3) O-ring
  - (4) RH timer cover
  - (5) O-ring
  - (6) Piston
  - (7) Sub-piston




- (c) Remove the nut from the LH timer cover.
- (d) Using a 5 mm hexagon wrench, remove the timer adjusting screw.
- (e) Remove the O-ring from the timer adjusting ring.

**28. REMOVE FUEL FEED PUMP**


- (a) Remove the two screws.
- (b) Using a piece of wire, remove the feed pump cover.
- (c) Remove the feed pump rotor, four blades and liner.

**NOTICE:**

- Be careful not to interchange the blade positions.
- Be careful not to damage the pump body.


**29. REMOVE REGULATOR VALVE**

Using SST, remove the regulator valve and two O-rings.  
SST 09260-54012 (09262-54020)

**30. REMOVE FUEL INLET HOLLOW SCREW**

Remove the hollow screw and gasket.






## INSPECTION OF INJECTION PUMP COMPONENTS


**NOTICE:** Do not touch the sliding surfaces of the pump plunger and delivery valves.

### 1. INSPECT DELIVERY VALVES (IPZ and iHZ)


- (a) Pull up the valve and close the hole at the valve seat bottom end with your thumb. When the valve is released, it should sink down quickly and stop at the position where the relief ring closes the valve seat hole.



- (b) Close the hole at the valve seat bottom end with your thumb. Insert the valve into the valve seat and press down with your finger. When your finger is released, the valve should rise back to its original position.



- (c) Remove your thumb from the valve seat hole. The valve should close completely by its own weight. If operation is not as specified, replace the valve as a set. **HINT:** Before using a new valve set, wash off the rust prevention compound with light oil or gasoline. Then re-wash with diesel fuel and perform the above tests.





### (1HD-T)

Pull up the valve. When the valve is released, it should sink down quickly.


If operation is not as specified, replace the valve as a set.

**HINT:** Before using a new valve set, wash off the rust prevention compound with light oil or gasoline. Then re-wash with diesel fuel and perform the above tests.





FU0180




FU2731

## 2. INSPECT PUMP PLUNGER, SPILL RING AND DISTRIBUTIVE HEAD

- Tilt the spill ring (distributive head) slightly and pull out the plunger.
- When released, the plunger should sink down smoothly into the spill ring (distributive head) by its own weight.
- Rotate the plunger and repeat the test at various positions.

If the plunger sticks at any position, replace the parts as a set.

- Insert the governor link ball pin into the spill ring and check that it moves smoothly without any play.




EM0988

## 3. INSPECT PLUNGER SPRINGS FOR SQUARENESS

Using a steel square, check the squareness of the plunger springs.

**Maximum squareness: 2.0 mm (0.079 in.)**

If squareness is greater than maximum, replace the springs.



EM0801

## 4. INSPECT SPRING LENGTH

Using vernier calipers, measure the free length of each spring.

**Spring free length:**

**Delivery valve spring**

1 PZ and 1 HZ	24.4 mm (0.961 in.)
1 HD-T	19.1 mm (0.752 in.)

**Plunger spring**

1 PZ and 1 HZ	30.0 mm (1.181 in.)
1 HD-T	31.2 mm (1.228 in.)

**Coupling spring**

1 PZ and 1 HZ	16.6 mm (0.654 in.)
1 HD-T	15.5 mm (0.610 in.)


**Pneumatic bellows spring (w/ HAC)**

1 PZ and 1 HZ (w/ HAC)	35.0 mm (1.378 in.)
------------------------	---------------------

**Boost compensator spring**

1 HD-T (Europe)	19.7 mm (0.776 in.)
1 HD-T (Others w/o BACS)	19.6 mm (0.772 in.)
1 HD-T (Others w/ BACS)	21.8 mm (0.858 in.)

If the free length is not as specified, replace the spring(s).




### 5. INSPECT ROLLER RING AND ROLLERS

Using a dial indicator, measure the roller height.

**Roller height variation: 0.02 mm (0.0008 in.)**


If the variation is greater than specification, replace the roller ring and roller as a set.



### 6. INSPECT FUEL CUT SOLENOID

- Connect the solenoid valve body and terminal to the battery terminals.
- You should feel the click from the solenoid valve when the battery power is connected and disconnected.

If the solenoid valve is not operating properly, replace it.




### 7. INSPECT PICKUP SENSOR

Using an ohmmeter, measure the resistance between the terminals.

**Resistance: 600 - 800 Q**


If resistance is not as specified, replace the sensor.



### 8. IF NECESSARY, REPLACE OIL SEAL


- Using a wrench, pry out the oil seal.

**NOTICE: Be careful not to damage to the pump body.**



- Apply **NP** grease to the lip of a new oil seal.

- Using a 22 mm socket wrench, tap in the oil seal until its surface is flush with the pump housing.




## ASSEMBLY OF INJECTION PUMP

(See pages FU-30, 31,32)

### 1. MOUNT PUMP BODY TO SST (STAND)


SST 09241 -76022 and 09245-54010



### 2. INSTALL FUEL INLET HOLLOW SCREW

Install a new gasket and the hollow screw.

**Torque: 375 kg-cm (27 ft-lb, 37 N·m)**




### 3. INSTALL REGULATOR VALVE

(a) Install the two O-rings to the regulator valve.

(b) Using SST, install the regulator valve.

SST 09260-54012 (09262-54020)

**Torque: 90 kg-cm (78 in.-lb, 8.8 N·m)**



### 4. INSTALL FUEL FEED PUMP

(a) Install the liner, rotor and four blades.


(b) Check that the liner and blades are facing in the correct direction, as shown.

(c) Check that the blades move smoothly.

(d) Align the fuel outlet holes of the cover and liner.

(e) Install the pump cover with the two screws.


**Torque: 25 kg-cm (22 in.-lb, 2.5 N·m)**




(f) Check that the rotor moves smoothly.

## 5. INSTALL DRIVE SHAFT


- (a) Install the drive gear on the drive shaft as shown.




- (b) Install two new joint rubbers into the drive gear.




- (c) Position the key groove of the feed pump rotor upward.




- (d) Install the set key and drive shaft washer on the drive shaft and insert the drive shaft assembly into the pump housing.




- (e) Check that the drive shaft turns without catching.






## 6. INSTALL TIMER PISTON

- (a) Apply No. 50 DENSO grease to the timer piston.
- (b) Install the sub-piston into the timer piston.




- (c) Insert the timer piston into the pump housing.




## 7. INSTALL ROLLER RING


- (a) (1PZ)  
Install the slide pin, three rollers and washers on the roller ring as shown in the illustration.




- (b) (1 HZ and 1HD-T)  
Install the slide pin, four rollers and washers on the roller ring.
- (c) Check that the roller is facing the flat surface of the washer.
- (d) Install the roller ring into the pump housing.



- (e) Carefully install the slide pin into the sub-piston.




- (e) Install the stopper pin and clip.




## 8. INSTALL TIMER SPRING


- (a) Install a new O-ring to the timer adjusting screw.  
 (b) Using a 5 mm hexagon wrench, install the timer adjusting screw to the LH timer cover and temporarily install the nut.



- (c) Install the following parts:  
 (1) New O-ring  
 (2) RH timer cover  
 (3) Timer spring  
 (4) New O-ring  
 (5) LH timer cover, timer adjusting screw and nut assembly




- (d) Using a 5 mm hexagon wrench, install the the four bolts.



## 9. PRESET TIMER ADJUSTING SCREW

- (a) Using vernier calipers, measure the protrusion of the adjusting screw from the timer cover.

**Protrusion: 7.5-8.0 mm (0.295-0.315 in.)**



- (b) Using a 5 mm hexagon wrench, adjust the protrusion of the adjusting screw from the timer cover.

## 10. ADJUST PLUNGER SPRING SHIM

- (a) Install the following parts to the distributive head:

- (1) Two plunger spring guides
- (2) Two upper spring seats
- (3) Two plunger springs
- (4) Lower spring seat
- (5) Upper plunger plate
- (6) Lower plunger plate
- (7) Pump plunger

**HINT:** Do not assemble the plunger spring shims at this time.

- (b) Using vernier calipers, measure clearance A indicated in the illustration.
- (c) Determine the plunger spring shim size by using the following formula and chart.

IPZ and 1HZ

New plunger spring shim thickness =  $5.8 - A$

1HD-T

New plunger spring shim thickness =  $5.1 - A$

A .... Measured plunger position

Plunger spring shim selection chart for 1 PZ and 1 HZ


mm (in.)

Measured clearance	Shim thickness	Measured clearance	Shim thickness
More than 5.3 (0.209)	0.5 (0.020)	4.3 – 4.5 (0.169 – 0.177)	1.5 (0.059)
5.0 – 5.2 (0.196 – 0.205)	0.8 (0.031)	4.0 – 4.2 (0.157 – 0.165)	1.8 (0.071)
4.8 – 4.9 (0.189 – 0.193)	1.0 (0.039)	Less than 3.9 (0.154)	2.0 (0.079)
4.6 – 4.7 (0.181 – 0.185)	1.2 (0.047)	–	–

Plunger spring shim selection chart for 1 HD-T

mm (in.)

Measured clearance	Shim thickness	Measured clearance	Shim thickness
More than 4.6 (0.181)	0.5 (0.020)	3.6 – 3.8 (0.142 – 0.150)	1.5 (0.059)
4.3 – 4.5 (0.169 – 0.177)	0.8 (0.031)	3.3 – 3.5 (0.130 – 0.138)	1.8 (0.071)
4.1 – 4.2 (0.161 – 0.165)	1.0 (0.039)	Less than 3.2 (0.126)	2.0 (0.079)
3.9 – 4.0 (0.154 – 0.157)	1.2 (0.047)	–	–





## HINT:





- For a measurement between listed sizes, use the next larger size. Ex. If thickness is 1.1 mm (0.043 in.) by calculation, use a 1.2 mm (0.047 in.) shim.
- Select two shims which have the same thickness.

## 11. (IPZonly)

**ADJUST PLUNGER ADJUSTING SHIM**

(a) Install the coupling and face camplate.

HINT: Do not assemble the coupling spring.



- (b) Clean the plunger adjusting shim and contacting surface area.
- (c) Align the pin groove of the pump plunger with the face camplate pin.
- (d) Using SST, install the used plunger adjusting shim and pump plunger.
- SST 09260-54012 (09269-54030)

(e) Install the distributive head with the four bolts.

**Torque: 120 kg-cm (9 ft-lb, 12 N·m)****NOTICE: Be careful not to damage the pump plunger.**

(f) Using vernier calipers, measure dimension B indicated in the illustration.

- (g) Determine the plunger adjusting shim size by using the following formula and chart.

New adjusting shim thickness =  $T + (B - 3.3)$


T ... Thickness of used shim

B ... Measured plunger position

### Plunger adjusting shim selection chart


[illegible]

**EXAMPLE:** The 2.4 mm (0.094 in.) shim is installed and measured clearance is 3.7 mm (0.146 in.). Replace the 2.4 mm (0.094 in.) shim with a 2.8 mm (0.110 in.) shim.




- (h) Install a new plunger adjusting shim and recheck dimension B.

**Dimension B: 3.2-3.4 mm (0.126-0.134 in.)**




- (i) Remove the distributive head.
- (j) Using SST, remove the following parts:
  - (1) Pump plunger
  - (2) Plunger adjusting shim
  - (3) Face camplate

SST 09260-5401 2 (09269-54030)





## 12. (1 HZ and 1HD-T) INSTALL COUPLING



## 13. INSTALL FACE CAM PLATE

- (a) Face the drive shaft with the key groove facing upward.

- (b) Install the coupling spring and camplate with the camplate pin facing the governor cover side.




## 14. INSTALL GOVERNOR LINK

- (a) Using SST, install the governor link with two new gaskets and the two support bolts.

**Torque: 140 kg-cm (10 ft-lb, 14 N-m)**

SST 09260-54012 (09269-54040)

- (b) Check that the governor link moves smoothly.



## 15. INSTALL PUMP PLUNGER


- (a) (1PZ)

Place the previously used plunger adjusting shim on center of the camplate.

- (1 HZ and 1HD-T)

Place the previously used plunger adjusting shim on the center of the camplate.


**NOTICE: Do not apply grease to the shim.**



(b) Install the following parts to the pump plunger:

- (1) Lower plunger plate
- (2) Upper plunger plate
- (3) Lower spring seat
- (4) Spill ring

HINT: Face the spill ring with the hole facing the lower spring seat.




(c) Align the pin groove of the plunger with the pin of the face camplate.

(d) Align the ball pin of the governor link with the pin hole of the spill ring.

(e) Using SST, install the pump plunger and two plunger springs.

SST 09260-5401 2 (09269-54030)





## 16. INSTALL DISTRIBUTIVE HEAD

(a) Apply No.50 DENSO grease to the following parts and install them to the distributive head:

- (1) Two plunger spring guides
- (2) Two new selected plunger spring shims
- (3) Two upper spring seats
- (4) Two lever support springs
- (5) New O-ring

(b) Install the distributive head.


**NOTICE:** Be careful not to damage the pump plunger.



(c) Using 5 mm hexagon wrench, install the four bolts.

**Torque: 120 kg-cm (9 ft-lb, 12 Nm)**

HINT: Use the bolt which is 45 mm (1.77 in.) in length.




### 17. INSTALL DELIVERY VALVE HOLDERS

- Install new gaskets and the valves into the distributive head.
- Install the spring seats and springs into the delivery valve holders.
- Using SST, install the delivery valve holders.

SST 09260-54012 (09269-54020)

#### Torque:

<b>1PZ and 1HZ</b>	<b>500 kg-cm (36 ft-lb, 49 M-m)</b>
<b>1HD-T</b>	<b>550 kg-cm (40 ft-lb, 54 Nm)</b>




### 18. (IPZonly)

#### INSTALL DISTRIBUTIVE HEAD PLUG

- Install a new O-ring to the head plug.
- Using SST, install the head plug.

SST 09260-54012 (09262-54010)


**Torque: 700 kg-cm (51 ft-lb, 69 N-m)**



### 19. INSTALL GOVERNOR SHAFT AND FLYWEIGHT HOLDER

- Install the following parts to the flyweight holder:
  - Four flyweight
  - No.2 flyweight washer
  - Governor sleeve

**HINT:** Replace the four flyweights as a set.





- Install a new O-ring to the governor shaft.
- Place the flyweight holder assembly (1) in position, and install the No.1 flyweight washer (2) and governor gear adjusting washer (3) between the flyweight holder and pump housing.
- Install the governor shaft through the governor gear adjusting washer, No.1 flyweight washer and flyweight holder assembly.
- Using a 5 mm hexagon wrench, turn the governor shaft counterclockwise.

### 20. CHECK FLYWEIGHT HOLDER THRUST CLEARANCE

Using a thickness gauge, measure the thrust clearance between the housing pin and flyweight holder.

**Thrust clearance: 0.15-0.35 mm  
(0.0059-0.0138 in.)**






If the thrust clearance is not as specified, adjust with a governor gear adjusting washer.

**Governor gear adjusting washer thickness:**

- 1.05 mm (0.0413 in.)
- 1.25 mm (0.0492 in.)
- 1.45 mm (0.0571 in.)
- 1.65 mm (0.0650 in.)
- 1.85 mm (0.0728 in.)




**21. ADJUST PROTRUSION OF GOVERNOR SHAFT**


- (a) Using vernier calipers, measure the protrusion of the governor shaft.

**Protrusion: 0.5-2.0 mm (0.020-0.079 in.)**

If the protrusion is not as specified, adjust by turning the governor shaft.




- (b) Install and tighten the nut while holding the governor shaft with a 5 mm hexagon wrench.




**22. (1 PZ (w/ HAC) and 1 HZ (w/ HAC))  
ASSEMBLE HIGH ALTITUDE COMPENSATOR**

**Install control lever**


- (a) Insert the connecting pin into governor cover.



- (b) Using a small screwdriver, install the control lever with the support pin.




- (c) Using a 4 mm hexagon wrench, install two new gaskets and the two bolts.



### 23. (1HD-T) ASSEMBLE BOOST COMPENSATOR

#### A. Install No.2 overflow screw


Install the No.2 overflow screw and cover.



#### B. Install No.2 PCS lever


Install the following parts to the governor cover:

- (1) Plate washer
- (2) O-ring
- (3) No.2 lever, O-ring and washer assembly




#### C. Install control lever


- (a) Insert the connecting pin into governor cover.



- (b) Using a small screwdriver, install the control lever with the support pin.




- (c) Using a 4 mm hexagon wrench, install two new gaskets and the two bolts.



## 24. INSTALL ADJUSTING LEVER SHAFT TO GOVERNOR SHAFT


Install the following parts to the governor cover:

- (1) Plate washer
- (2) New O-ring
- (3) Adjusting lever shaft, O-ring and plate washer assembly



## 25. INSTALL GOVERNOR COVER

- (a) Install the speed control spring to the adjusting shaft.
- (b) Install a new gasket to the groove of the governor cover.
- (c) Install the damper spring and spring seat, and connect the speed control spring to the spring seat.



- (d) Using a 5 mm hexagon wrench, install the governor cover with the four bolts.


Torque: 85 kg-cm (74 in.-lb, 8.3 N·m)

HINT: Use the bolt which is 35 mm (1.38 in.) in length.


- (e) (w/ HAC and 1HD-T)  
Install the idle speed adjusting screw.

## 26. INSTALL ADJUSTING LEVER


- (a) Place the return spring on the governor cover.








- (b) Hook the return spring to the adjusting lever, and turn and place the adjusting lever on the governor shaft.
- (c) Align the lines of the adjusting lever shaft and adjusting lever.




- (d) Install the adjusting lever with the spring guide and nut.



**27. (w/TACHOMETER)  
INSTALL PICKUP SENSOR**

- (a) Install a new O-ring and pickup sensor.
- (b) Connect the two lead wires to the connector.

**Torque: 210 kg-cm (15 ft-lb, 21 N·m)**




FU2915

## 28. (1HZand1HD-Tonly) ADJUST PLUNGER PRE-STROKE

- (a) Install SST to the fuel cut solenoid installation screw section.

SST 09275-17010

- (b) Set the dial indicator so that the tip of the dial indicator push rod touches the upper surface of the plunger.
- (c) Rotate the drive shaft, set the plunger to BDC and set the scale on the dial indicator to 0 mm (0 in.)



FU2916

- (d) Apply a few drops of light oil (diesel fuel) to the top surface of the plunger, and when  $0.1 \text{ kg/cm}^2$  (1.4 psi, 49 kPa) of air is applied to SST, bubbles appear on the upper surface of the plunger.

SST 09275-17010

- (e) Slowly rotate the drive shaft in the pump rotation direction (clockwise) and read the dial indicator when the bubbles on the top of the plunger disappear.

**Pre-stroke: 0.15-0.25 mm (0.0059- 0.0098 in.)**

If the pre-stroke is not as specified, replace the plunger adjusting shim under the plunger with a different sized shim.


Adjusting shim thickness			mm (in.)
1.90 (0.0748)	2.35 (0.0925)	2.80 (0.1102)	
1.95 (0.0768)	2.40 (0.0945)	2.85 (0.1122)	
2.00 (0.0787)	2.45 (0.0965)	2.90 (0.1142)	
2.05 (0.0807)	2.50 (0.0984)	2.94 (0.1157)	
2.10 (0.0827)	2.55 (0.1004)	2.99 (0.1177)	
2.15 (0.0846)	2.60 (0.1024)	3.04 (0.1197)	
2.20 (0.0866)	2.65 (0.1043)	3.09 (0.1216)	
2.25 (0.0886)	2.70 (0.1063)	3.14 (0.1236)	
2.30 (0.0906)	2.75 (0.1083)	3.19 (0.1256)	

**HINT:** If the shim is made thicker, the pre-stroke is decreased


- (f) After completing the pre-stroke adjustment, check that dimension B is within specifications.

**Dimension B: 2.8-3.2 mm (0.110-0.126 in.)**

If dimension B is not within the specification, replace the distributor head.




FU2914

**29. (1HZ and 1HD-T)****INSTALL DISTRIBUTIVE HEAD PLUG**


- (a) Install a new O-ring to the head plug.
- (b) Using SST, install the head plug.

SST 09260-5401 2 (09262-54010)

**Torque:** 1HZ 700 kg-cm (51 ft-lb, 69 Nm)  
1HD-T 900 kg-cm (65 ft-lb, 88 Nm)


**30. (1 PZ (w/ HAC) and 1 HZ (w/ HAC))****ASSEMBLE HIGH ALTITUDE COMPENSATOR****A. Install pneumatic bellows**

- (a) Insert 3-4 cc (0.18-0.24 cu in.) of engine oil into the bushing hole.




- (b) Place the following parts on the governor cover:

- (1) Pneumatic bellows spring
- (2) Push rod




- (c) Install the following parts to the pneumatic bellows cover:

- (1) Pneumatic bellows
- (2) Two rubber caps
- (3) Pneumatic bellows and two rubber caps assembly
- (4) Shims




- (d) Install a new gasket and the pneumatic bellows and bellows cover assembly to the governor cover.

- (e) Using a 5 mm hexagon wrench, install the four bolts.



### B. Install lever control spring

Install the lever control spring with a new gasket and the bolt.



## 31. (1HD-T)

### ASSEMBLE BOOST COMPENSATOR


#### A. Install guide bushing

Install and adjust the guide bushing to the dimension "A" as shown in the illustration.

##### Dimension "A":

Europe 19.2-19.3 mm (0.755- 0.760 in.)

Others 18.6-18.7 mm (0.732- 0.736 in.)



#### B. Install boost compensator diaphragm

##### (a) Adjust boost compensator shim

(1) Place the shim on the guide bushing

(2) Using vernier calipers, measure the dimension "B" as shown in the illustration.

##### Dimension "B":


Europe 4.8-5.0 mm (0.189-0.197 in.)

Others 6.0-6.2 mm (0.236-0.244 in.)

If the dimension is not within specification, select and install the correct shim.

##### Adjusting shim thickness:

1.1 mm	(0.043 in.)
1.3 mm	(0.051 in.)
1.5 mm	(0.059 in.)
1.7 mm	(0.067 in.)
1.9 mm	(0.075 in.)
2.1 mm	(0.083 in.)
2.3 mm	(0.090 in.)
2.5 mm	(0.098 in.)
2.7 mm	(0.106 in.)
2.9 mm	(0.114 in.)
3.1 mm	(0.122 in.)
3.3 mm	(0.130 in.)



- (b) Adjust the installation direction of boost compensator diaphragm.

(1) Install the shim and diaphragm.

HINT: Do not assemble the spring.


(2) While pushing on the diaphragm, measure dimension "X" with vernier calipers as shown.

**Dimension "X": 6.9-7.1 mm  
(0.272-0.280 in.)**


HINT: Measure at the center of the hole.

(3) Place matchmarks on the diaphragm and governor cover.

(4) Remove the diaphragm.




- (c) Insert 1.5-2.5 cc (0.09-0.15 cu in.) of engine oil into the bushing hole.




- (d) Install spring, shim and diaphragm.

- (e) Align the matchmarks on the diaphragm and governor cover.




- (f) Using a 5 mm hexagon wrench, install the four bolts.



### C. Install lever control spring


Install the lever control spring with a new gasket and the bolt.




### 32. INSTALL FUEL CUT SOLENOID

- (a) Install a new O-ring on the fuel cut solenoid.
- (b) Install the strainer, valve, spring, a new gasket and the fuel cut solenoid.

**Torque: 225 kg-cm (16 ft-lb, 22 N·m)**




- (c) Install the lead wire to the fuel cut solenoid with the nut.
- (d) Install the dust cover to the fuel cut solenoid.
- (e) Install the lead wire connector to bracket.




### 33. (w/ Dash Pot) INSTALL DASH POT

Install the dash pot and gasket.



### 34. (w/ PCS) INSTALL NO.1 PCS LEVER


- (a) Align the lines of the levers.



(b) Install the nut.


**35. (w/ PCS)  
INSTALL PCS ACTUATOR**

(a) Using a 5 mm hexagon wrench, install the PCS actuator assembly with the two bolts.



(b) Install the clip.

(c) Install the PCS adjusting screw.




**36. (w/ ACSD)**


**INSTALL THERMO WAX**


(a) Using a screwdriver, turn the cold starting lever counterclockwise approx. 20°.

(b) Put a metal plate (thickness of 3.5-7.5 mm (0.138-0.295 in.)) between the cold starting lever and thermo wax plunger.



(c) Install a new O-ring and the thermo wax with the two bolts.






**37. (w/ ACSD)  
INSTALL IDLE-UP LEVER**

Using a 5 mm hexagon wrench, install the idle-up lever with the three bolts.


**38. (w/ A/C)  
INSTALL IDLE-UP ACTUATOR**

**39. REMOVE INJECTION PUMP FROM SST (STAND)**  
SST 09241 -76022 and 09245-54010



**40. PERFORM AIR TIGHT TEST**

(a) Install a bolt to the overflow port.



(b) Connect an air hose to the fuel inlet pipe and place the injection pump into diesel fuel.

(c) Apply 0.5 kg/cm<sup>2</sup> (7 psi, 49 kPa) of pressure and confirm that there are no leaks.

(d) Next check that there are no leaks with 5.0 kg/cm<sup>2</sup> (71 psi, 490 kPa) of pressure applied.

**41. INSTALL SET KEY OF INJECTION PUMP DRIVE PULLEY ON DRIVE SHAFT**



## ADJUSTMENT OF INJECTION PUMP

### 1. PRETEST CHECK AND PREPARATION

- (a) The specifications for test nozzle and nozzle holders are as follows.

**Test nozzle: DN12SD12 (NIPPONDENSO)**

**Test nozzle opening pressure:**

**145-155 kg/cm<sup>2</sup>**

**(2,062- 2,205 psi, 14,220-15,200 kPa)**

- (b) Check the accuracy of the tachometer.

**Allowable error: ± 40 rpm**

- (c) Install the angle gauge stand.

- (d) Mount the injection pump body on the pump tester.

**HINT:** Place a mark on the key groove portion of the coupling.

- (e) Install an injection pipe with the following specifications.

**Outer diameter: 6.0 mm (0.236 in.)**






**Inner diameter: 2.0 mm (0.079 in.)**



**Length: 840 mm (33.07 in.)**

**Minimum bending radius: 25 mm (0.98 in.) or more**

- (f) Remove the fuel inlet hollow screw.

- (g) Connect the fuel inlet pipe with an adapter.





(h) Install the overflow hose with the overflow screw.  
HINT: Always use the overflow screw installed on the pump to be adjusted.

(i) Using a 5 mm hexagon wrench, remove the two bolts and RH timer cover.

(j) Install the inner pressure gauge with the timer measuring device.

Part No. 95095-10220 and 95095-10231


(NIPPONDENSO)

HINT: Bleed the air by the air bleed screw.

(k) (1HD-T)  
Connect SST (turbocharger pressure gauge) to the boost compensator.


SST 09992-00241

1PZ





FU2721

1HZ





FU2720




- (l) (12 V type)  
Apply approx. 6 volts of DC power to the fuel cut solenoid.
- (m) (24 V type)  
Apply approx. 12 volts of DC power to the fuel cut solenoid.

**NOTICE:**

- When applying voltage to the solenoid, position the battery as far away from the solenoid as possible so that a spark does not occur.
  - When connecting the battery cable, connect the solenoid side first.
- (n) The pressure for feeding fuel to the injection pump should be  $0.2 \text{ kg/cm}^2$  (2.8 psi, 20 kPa). The fuel temperature for pump testing should be  $40-45^\circ\text{C}$  ( $104-113^\circ\text{F}$ ).




- (o) Install an angle gauge to the stand and set it to the adjusting lever.
- (p) Secure the adjusting lever fully on the maximum speed side.




(q) Check the installation direction of the camplate as follow:

- (1PZ)  
Disconnect the injection pipe from the position marked "A" on the distributive head.



- (1 HZ and 1HD-T)  
Disconnect the injection pipe from the position marked "C" on the distributive head.
- Using SST, remove the delivery valve holder.

SST 09260-54012 (09269-54020)





- Check that fuel is flowing out when the mark is in the position shown in the illustration.



If not, it is improperly assembled.

- Disassemble and change the camplate position 180° in the opposite direction.


**HINT:** At this time, disconnect the fuel cut solenoid wire harness.



- Using SST, install the delivery valve holder.
- SST 09260-54012 (09269-54020)
- Connect the injection pipe.




(r) Bleed the air from the injection pipes.



(s) Race the injection pump for 5 minutes at 2,000 rpm.

**NOTICE:** Check that there is no fuel leakage or abnormal noise.






**HINT:**

- Measure the volume of each injection cylinder with a measuring cylinder.
- Before measuring the injection volume first hold the cylinder tilted for at least 30 seconds to discard all the fuel.


**2. PRESET FULL LOAD INJECTION VOLUME**

- (a) Set the adjusting lever to maximum position.
- (b) (1PZ (w/ HAC) and 1HZ (w/ HAC))  
Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.
- (c) (1HD-T (w/o BACS))  
Apply  $0.81 \text{ kg/cm}^2$  (11.5 psi, 79 kPa) of pressure to the boost compensator.
- (d) (1HD-T (w/ BACS))  
Apply  $1.29 \text{ kg/cm}^2$  (18.3 psi, 127 kPa) of pressure to the boost compensator.
- (e) (1HD-T (w/ PCS))  
Apply vacuum to the PCS actuator.
- (f) Measure the injection volume.

Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1PZ	1,200	200	11.78 – 12.18 (0.72 – 0.74)
1HZ	1,200	200	11.80 – 12.20 (0.72 – 0.74)
1HD-T (w/o BACS)	1,800	200	13.58 – 14.18 (0.83 – 0.87)
1HD (w/ BACS)	1,800	200	13.14 – 13.74 (0.80 – 0.84)



- (g) Remove the collar seal as follows:
  - Hold the full load set screw, and release the collar seal from the spot weld by turning the lock nut counterclockwise by 90° or more.
  - Using a screwdriver, remove the collar seal.
- (h) (w/ Wire Seal Type)  
Cut off the wire seal.
- (i) Adjust by turning the full load set screw.  
HINT: The injection volume will increase about 3 cc (0.18 cu in.) with each 1/2 turn of the screw.



### 3. (w/o HIGH ALTITUDE) PRE-SETTING OF LOAD SENSING TIMER

Using a 5 mm hexagon wrench, adjust the protrusion of the governor shaft.


**Protrusion: 0.5-2.0 mm (0.020-0.079 in.)**

### 4. PRESET MAXIMUM SPEED

- Set the adjusting lever to maximum position.
- (1 PZ (w/ HAC) and 1 HZ (w/ HAC))  
Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.
- (1HD-T (w/o BACS))  
Apply  $0.81 \text{ kg/cm}^2$  (11.5 psi, 79 kPa) of pressure to the boost compensator.
- (1HD-T (w/ BACS))  
Apply  $1.29 \text{ kg/cm}^2$  (18.3 psi, 127 kPa) of pressure to the boost compensator.
- (1HD-T (w/ PCS))  
Apply vacuum to the PCS actuator.
- Measure the injection volume.


Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1PZ	2,300	200	4.0 – 6.0 (0.24 – 0.37)
1HZ	2,300	200	3.0 – 5.0 (0.18 – 0.31)
1HD-T	2,200	200	3.0 – 5.0 (0.18 – 0.31)


- Cut off the seal wire.
- Adjust the injection volume with the maximum speed adjusting screw.



### 5. ADJUST PUMP INNER PRESSURE

- Measure the pump inner pressure at the below listed rpm.






Item	Pump rpm	Inner pressure kg/cm <sup>2</sup> (psi, kPa)
1PZ	500	2.45 – 3.05 (35 – 43, 240 – 299)
	2,000	6.4 – 7.0 (91 – 100, 628 – 686)
1HZ	500	2.5 – 3.1 (36 – 44, 245 – 304)
	2,000	7.1 – 7.7 (101 – 110, 696 – 755)
1HD-T (w/o BACS)	400	2.2 – 3.1 (31 – 44, 216 – 304)
	1,900	8.1 – 8.4 (115 – 119, 794 – 824)
	2,200	9.0 (128, 883) or less
1HD-T (w/ BACS)	400	2.7 – 3.6 (38 – 51, 265 – 353)
	2,200	8.7 – 9.0 (124 – 128, 853 – 893)

(b) If the pressure is low, adjust by lightly tapping the regulator valve piston while watching the pressure gauge.

HINT: If the pressure is too high or if the regulator valve was tapped in too far, the regulator valve must be replaced.




## 6. CHECK OVERFLOW VOLUME

Measure the overflow volume at the below listed rpm.

Item	Pump rpm	Overflow volume cc/min. (cc in./min.)
1PZ and 1HZ	2,000	366 – 800 (22.3 – 48.8)
1HD-T	1,900	583 – 1,083 (35.6 – 66.1)

HINT: Always use the overflow screw installed on the pump to be adjusted.




## 7. (w/ ACSD)

### RELEASE COLD STARTING SYSTEM FOR NEXT INSPECTIONS

- Using a screwdriver, turn the cold starting lever counterclockwise approx. 20°.
- Put a metal plate (thickness of 3.5-7.5 mm (0.138-0.295 in.)) between the cold starting lever and thermo wax plunger.

HINT: Keep the cold starting system released until all measurements and adjustments are finished.



## 8. ADJUST TIMER

- Set the timer measuring device at zero.



- (b) Measure the timer piston stroke at the below listed rpms.

Item	Pump rpm	Timer piston stroke mm (in.)
1PZ	600	0.58 – 1.58 (0.0288 – 0.0622)
	1,200	3.02 – 4.02 (0.1189 – 0.1583)
	1,600	4.65 – 5.65 (0.1830 – 0.2224)
	2,000	6.28 – 7.28 (0.2472 – 0.2866)
	2,500	6.88 – 7.88 (0.2709 – 0.3102) (LST non-operative)
1HZ	600	0.43 – 1.43 (0.0169 – 0.0563)
	1,200	3.23 – 4.23 (0.1272 – 0.1665)
	1,600	5.09 – 6.09 (0.2004 – 0.2398)
	2,000	6.88 – 7.88 (0.2709 – 0.3102)
	2,500	6.88 – 7.88 (0.2709 – 0.3102) (LST non-operative)
1HD-T (Europe)	1,300	1.4 – 2.4 (0.055 – 0.094)
	1,440	3.0 – 4.0 (0.118 – 0.157)
	1,700	5.9 – 6.9 (0.232 – 0.272)
	1,900	7.7 – 8.7 (0.303 – 0.343)
1HD-T (Others)	800	1.05 – 2.05 (0.0413 – 0.0807)
	1,400	4.9 – 5.9 (0.193 – 0.232)
	1,700	6.42 – 7.42 (0.2528 – 0.2921)
	1,900	7.7 – 8.7 (0.303 – 0.343)

HINT: Check that the hysteresis is within 0.3 mm (0.012 in.)

- (c) Using a 5 mm hexagon wrench, adjust by the timer adjusting screw.

HINT: The stroke will decrease with turn to clockwise and increase with turn to counterclockwise.

## 9. (1HD-T)

### CHECK AIR TIGHTNESS OF BOOST COMPENSATOR




- (a) Apply 1.00 kg/cm<sup>2</sup> (14.2 psi, 98 kPa) of pressure to the boost compensator.
- (b) Measure the time it takes for the pressure to drop to 0.97 kg/cm<sup>2</sup> (13.8 psi, 95 kPa).

**Pressure drop: 10 seconds or more**

## 10. ADJUST FULL LOAD INJECTION VOLUME


- (a) The adjusting lever angle for the adjustment below should be as shown in the illustration.

Adjusting lever angle	
A (Maximum speed side)	B (Idle speed side)
Plus 21 – 31°	Minus 12 – 22°



- (b) (1 PZ (w/ HAC) and 1 HZ (w/ HAC))  
Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.
- (c) (1HD-T (w/o BACS))  
Apply  $0.81 \text{ kg/cm}^2$  (11.5 psi, 79 kPa) of pressure to the boost compensator.
- (d) (1HD-T (w/ BACS))  
Apply  $1.29 \text{ kg/cm}^2$  (18.3 psi, 1 27 kPa) of pressure to the boost compensator.
- (e) (1HD-T (w/ PCS))  
Apply vacuum to the PCS actuator.
- (f) Measure the full load injection volume.


Item	Adjusting lever angle	Pump rpm	No. of measuring strokes	Injection volume cc (cc in.)
1PZ	Plus $21 - 31^\circ$	1,200	200	11.78 – 12.18 (0.72 – 0.74)
1HZ	Plus $21 - 31^\circ$	1,200	200	11.80 – 12.20 (0.72 – 0.74)
1HD-T (w/o BACS)	Plus $21 - 31^\circ$	1,100	200	13.58 – 14.18 (0.83 – 0.87)
1HD-T (w/ BACS)	Plus $21 - 31^\circ$	1,100	200	13.14 – 13.74 (0.80 – 1.84)



- (g) Adjust by turning the full load set screw.  
HINT: The injection volume will increase about 3 cc (0.18 cu in.) with each 1/2 turn of the screw.

- (h) (1HD-T (w/ PCS))  
Release the vacuum to the PCS actuator.
- (i) (1HD-T (w/PCS))  
Measure the injection volume.


Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1,100	200	11.0 – 12.2 (0.67 – 0.74)



(j) (1HD-T(w/ PCS))

Adjust by turning the PCS adjusting screw.

HINT: By screwing in the adjusting screw, the injection volume is increased; unscrewing the adjusting screw decreases the injection volume.



(k) (1HD-T (w/PCS))

Apply vacuum to the PCS actuator and check that the clearance between No.1 PCS lever and adjusting screw at least 3 mm (0.12 in.).

## 11. ADJUST MAXIMUM SPEED

(a) (1PZ (w/HAC) and 1HZ (w/HAC))

Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.

(b) (1HD-T (w/o BACS))

Apply  $0.81 \text{ kg/cm}^2$  (11.5 psi, 79 kPa) of pressure to the boost compensator.

(c) (1HD-T (w/ BACS))


Apply  $1.29 \text{ kg/cm}^2$  (18.3 psi, 127 kPa) of pressure to the boost compensator.

(d) (1HD-T (w/ PCS))

Apply vacuum to the PCS actuator.

(e) Measure the injection volume at each pump rpm.

Item	Adjusting lever angle	pump rpm	No. of measuring strokes	Injection volume cc (cu in.)	Remarks
1PZ	Plus 21 – 31°	2,300	200	4.0 – 6.0 (0.24 – 0.37)	Adjust
		2,500		1.0 (0.06) or less	–
1HZ	Plus 21 – 31°	2,300	200	3.0 – 5.0 (0.18 – 0.31)	Adjust
		2,550		1.0 (0.06) or less	–
1HD-T	Plus 21 – 31°	2,200	200	3.0 – 5.0 (0.18 – 0.31)	Adjust
		2,350		1.0 (0.06) or less	–



- (f) Adjust by turning the maximum speed adjusting screw.

## 12. CHECK INJECTION VOLUME

- (a) (1 PZ (w/ HAC) and 1 HZ (w/ HAC))  
Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.
- (b) (1PZand1HZ)  
Measure the injection volume at each pump rpm.

Item	Adjusting lever angle	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)	Variation limit cc (cu in.)	Remarks
1PZ	Plus 21 – 31°	1,200	200	11.78 – 12.18 (0.72 – 0.74)	0.4 (0.02)	Basic full-load injection volume
		100		9.60 – 14.40 (0.59 – 0.88)	1.2 (0.07)	Volume during starting
		500		10.56 – 11.76 (0.64 – 0.72)	0.6 (0.04)	–
		2,000		11.62 – 12.82 (0.71 – 0.78)	0.6 (0.04)	–
1HZ	Plus 21 – 31°	1,200	200	11.80 – 12.20 (0.72 – 0.74)	0.4 (0.03)	Basic full-load injection volume
		100		9.60 – 14.40 (0.59 – 0.88)	1.2 (0.07)	Volume during starting
		500		9.74 – 10.94 (0.59 – 0.67)	0.6 (0.04)	–
		2,000		10.96 – 12.16 (0.67 – 0.74)	0.6 (0.04)	–


(c) (1HD-T (w/ PCS))

Apply vacuum to the PCS actuator.

(d) (1HD-T)

Measure the injection volume at each pump rpm and boost pressure.


Item	Adjusting lever angle	Pump rpm	Boost pressure kg/cm <sup>2</sup> (psi, kPa)	No. of measuring strokes	Injection volume cc (cu in.)	Variation limit cc (cu in.)	Remarks
1HD-T (Europe)	Plus 21 – 31°	1,100	0.81 (11.5, 79)	200	13.52 – 14.72 (0.83 – 0.90)	0.6 (0.04)	Basic full-load injection volume
		100	0 (0, 0)		11.60 – 16.40 (0.71 – 1.00)	1.2 (0.07)	Volume during starting
		500	0 (0, 0)		8.32 – 9.12 (0.51 – 0.56)	0.6 (0.04)	—
		1,800	0.81 (11.5, 79)		13.58 – 14.18 (0.83 – 0.87)	1.2 (0.07)	—
1HD-T (Others) (w/o BACS)	Plus 21 – 31°	1,100	0.81 (11.5, 79)	200	11.70 – 12.90 (0.71 – 0.79)	0.6 (0.04)	Basic full-load injection volume
		100	0 (0, 0)		11.60 – 16.40 (0.71 – 1.00)	1.2 (0.07)	Volume during starting
		500	0 (0, 0)		8.68 – 9.48 (0.53 – 0.58)	0.6 (0.04)	—
		1,800	0.81 (11.5, 79)		13.58 – 14.18 (0.83 – 0.87)	1.2 (0.07)	—
1HD-T (Others) (w/ BACS)	Plus 21 – 31°	1,100	1.29 (18.3, 127)	200	11.70 – 12.90 (0.71 – 0.79)	0.6 (0.04)	Basic full-load injection volume
		100	0.50 (7.1, 49)		11.60 – 16.40 (0.71 – 1.00)	1.2 (0.07)	Volume during starting
		500	0.50 (7.1, 49)		8.20 – 9.20 (0.50 – 0.56)	0.6 (0.04)	—
		1,800	1.29 (18.3, 127)		13.14 – 14.74 (0.80 – 0.84)	1.2 (0.07)	—



If the injection volume at 100 rpm is not as specified, replace the governor sleeve plug as follows:


- Using SST and a press, press out the sleeve plug assembly from the governor sleeve.

SST 09236-00101 (09237-00070)



- Remove the E-ring and following parts from the sleeve plug:

- (1) Stop ring
- (2) Bearing and two bearing retainers




- Measure the head thickness of the sleeve plug, and select a new sleeve plug.


Sleeve plug head thickness for 1PZ and 1HZ mm (in.)		
3.0 (0.118)	3.5 (0.138)	4.0 (0.158)
3.1 (0.122)	3.6 (0.142)	4.1 (0.161)
3.2 (0.126)	3.7 (0.146)	4.2 (0.165)
3.3 (0.130)	3.8 (0.150)	
3.4 (0.134)	3.9 (0.154)	

Sleeve plug head thickness for 1HD-T mm (in.)		
3.0 (0.118)	4.3 (0.169)	5.6 (0.220)
3.1 (0.122)	4.4 (0.173)	5.7 (0.224)
3.2 (0.126)	4.5 (0.177)	5.8 (0.228)
3.3 (0.130)	4.6 (0.181)	5.9 (0.232)
3.4 (0.134)	4.7 (0.185)	6.0 (0.236)
3.5 (0.138)	4.8 (0.189)	6.1 (0.240)
3.6 (0.142)	4.9 (0.193)	6.2 (0.244)
3.7 (0.146)	5.0 (0.197)	6.3 (0.248)
3.8 (0.150)	5.1 (0.201)	6.4 (0.252)
3.9 (0.154)	5.2 (0.205)	6.5 (0.256)
4.0 (0.158)	5.3 (0.209)	6.6 (0.260)
4.1 (0.161)	5.4 (0.213)	
4.2 (0.165)	5.5 (0.216)	

HINT: Lengthening the plug 0.1 mm (0.004 in.) will decrease injection volume by 0.6 cc (0.04 cu in.).



- Install the following parts to the new sleeve plug with a new E-ring:
  - (1) Bearing and two retainers
  - (2) Stop ring




- Using a press, press in the sleeve plug assembly to the governor sleeve.

### 13. (1HD-T) ADJUST FULL LOAD MINIMUM INJECTION VOLUME

(a) Measure the injection volume.

Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
Europe	500	200	8.32 – 9.12 (0.51 – 0.56)
Others (w/o BACS)	500	200	8.68 – 9.48 (0.53 – 0.58)
Others (w/ BACS)	500	200	7.54 – 8.34 (0.46 – 0.51)

(b) Using a hexagon wrench, adjust the timer slide pin.



### 14. (1HD-T) ADJUST BOOST COMPENSATOR CHARACTERISTIC


(a) Apply pressure to the boost compensator.


(b) Measure the injection volume bushing.

Item	Pump rpm	Boost pressure kg/cm <sup>2</sup> (psi, kPa)	No. of measuring strokes	Injection volume cc (cu in.)
Europe	1,100	0.48 (6.8, 47)	200	12.44 – 13.44 (0.76 – 0.82)
Others (w/o BACS)	1,100	0.54 (7.7, 53)	200	10.86 – 11.86 (0.66 – 0.72)
Others (w/ BACS)	500	0.50 (7.1, 49)	200	8.20 – 9.20 (0.50 – 0.56)

(c) Using a screwdriver, adjust the guide bushing.

HINT: When the guide bushing is turned clockwise, as seen from above, the injection volume will increase.





### 15. (1HD-T) INSPECT BOOST COMPENSATOR CHARACTERISTIC TENDENCY

- Apply pressure to the boost compensator.
- Measure injection volume.

Item	Pump rpm	Boost pressure kg/cm <sup>2</sup> (psi, kPa)	No. of measuring strokes	Injection volume cc (cu in.)
Europe	1,100	0.27 (3.8, 26)	200	10.50 – 11.70 (0.64 – 0.71)
Others (w/o BACS)	1,100	0.41 (5.8, 40)	200	9.48 – 10.68 (0.58 – 0.65)
Others (w/ BACS)	500	0.81 (11.5, 79)	200	9.80 – 11.00 (0.60 – 0.67)

### 16. (1HD-T) CHECK HYSTERESIS

#### (w/o BACS)

Compare the injection volume when the boost compensator pressure is lowered from 0.81 kg/cm<sup>2</sup> (11.5 psi, 79 kPa) to 0 kg/cm<sup>2</sup> (0 psi, 0 kPa) and, conversely, when it is raised from zero.

#### (w/ BACS)

Compare the injection volume when the boost compensator pressure is lowered from 1.25 kg/cm<sup>2</sup> (18.3 psi, 127 kPa) to 0 kg/cm<sup>2</sup> (0 psi, 0 kPa) and, conversely, when it is raised from zero.

**HINT:** Make measurements after moving the adjusting lever between idle and maximum three times for each lowering of the pressure.

Item	Pump rpm	Boost pressure kg/cm <sup>2</sup> (psi, kPa)	No. of measuring strokes	Injection volume cc (cu in.)	Hysteresis cc (cu in.)
Europe	1,100	0.81 (11.5, 79)	200	13.52 – 14.72 (0.82 – 0.90)	–
	1,100	0.48 (6.8, 47)	200	12.44 – 13.44 (0.76 – 0.82)	–
	1,100	0.27 (3.8, 26)	200	10.50 – 11.70 (0.64 – 0.71)	0.3 (0.02) or less
	1,100	0 (0, 0)	200	9.70 – 11.10 (0.59 – 0.68)	–
Others (w/o BACS)	1,100	0.81 (11.5, 79)	200	11.70 – 12.90 (0.71 – 0.79)	–
	1,100	0.54 (7.7, 53)	200	10.86 – 11.86 (0.66 – 0.72)	–
	1,100	0.41 (5.8, 40)	200	9.48 – 10.68 (0.58 – 0.65)	0.3 (0.02) or less
	1,100	0 (0, 0)	200	8.62 – 10.02 (0.53 – 0.61)	–



Cont'd

Item	Pump rpm	Boost pressure kg/cm <sup>2</sup> (psi, kPa)	No. of measuring strokes	Injection volume cc (cu in.)	Hysteresis cc (cu in.)
Others (w/ BACS)	1,100	1.29 (18.3, 127)	200	11.70 – 12.90 (0.71 – 0.79)	–
	500	0.81 (11.5, 79)	200	9.80 – 11.00 (0.60 – 0.67)	0.3 (0.02) or less
	500	0.50 (7.1, 49)	200	8.20 – 9.20 (0.50 – 0.56)	–
	500	0 (0, 0)	200	7.54 – 8.34 (0.46 – 0.51)	–



If not within standard value, check each sliding part of the boost compensator and check whether or not there is any oil.

#### 17. (w/o HIGH ALTITUDE) ADJUST LOAD SENSING TIMER


- Using a 5 mm hexagon wrench, adjust the starting and end points of the load sensing timer by turning the governor shaft.
- (1PZ (w/ HAC) and 1HZ (w/ HAC))  
Apply  $760 \pm 1.5$  mmHg ( $29.92 \pm 0.06$  in.Hg,  $101.3 \pm 0.2$  kPa) absolute pressure.
- (1HD-T (w/o BACS))  
Apply  $0.81$  kg/cm<sup>2</sup> (11.5 psi, 79 kPa) of pressure to the boost compensator.
- (1HD-T (w/ BACS))  
Apply  $1.29$  kg/cm<sup>2</sup> (18.3 psi, 127 kPa) of pressure to the boost compensator.
- (1HD-T (w/ PCS))  
Apply vacuum to the PCS actuator.
- Measure the injection volume.

Item	Adjusting lever position	Pump rpm	No. of measuring strokes
1PZ, 1HZ	Maximum speed side	1,600	200
1HD-T		1,800	

- Slowly move the adjusting lever from the maximum speed side to the idle speed side, and secure it at the point where the pump inner pressure begins to drop.
- Measure the injection volume at the drop point (starting point).




Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1PZ	1,600	200	Measured value at step (f) minus 1.4 (0.09) $\pm$ 0.3 (0.02)
1HZ	1,600	200	Measured value at step (f) minus 1.4 (0.09) $\pm$ 0.3 (0.02)
1HD-T (Europe)	1,800	200	Measured value at step (f) minus 1.6 (0.10) $\pm$ 0.6 (0.04)
1HD-T (Others)	1,800	200	Measured value at step (f) minus 1.2 (0.07) $\pm$ 0.2 (0.01)



- (i) Using a 5 mm hexagon wrench, adjust by turning the governor shaft, and perform the measurement again it is as specified.

HINT: The injection volume will increase approx. 3 cc (0.2 cu in.) with each 1/2 turn of the governor shaft.



- (j) (1PZ and 1HZ)  
Check the end point injection volume by slowly moving the adjusting lever from the maximum speed side to the idle speed side, and secure it at the point where the pump inner pressure stops dropping.

Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1PZ	1,600	200	9.08 – 9.88 (0.55 – 0.60)
1HZ	1,600	200	8.2 (0.50) or more

- (k) (1HD-T (Europe))  
Check the timer piston stroke when the the pump rpm is 1,440 rpm and injection volume is 8.4-9.2 cc (0.51 -0.56 cu in.).


**Timer piston stroke: 2.0 mm (0.079 in.) or less**

- (l) (1HD-T (Others))  
Check the injection volume when the pump rpm is 1,440 rpm and timer piston stroke is 3.7-4.3 mm (0.146- 0.169 in.).


**Injection volume: 6 cc (0.37 cu in.)**

HINT: The end point for 1HD-T engine is hard to identify, so use the methods used in (k) or (l) above.

- (m) Check the timer piston fluctuation when the adjusting lever is moved from the maximum speed side to the idle speed side.



Item	Pump rpm	Timer piston fluctuation mm (in.)
1PZ	1,600	2.19 – 3.19 (0.0862 – 0.1256)
1HZ	1,600	2.73 – 3.73 (0.1075 – 0.1469)
1HD-T (Europe)	1,440	0.70 – 1.70 (0.0276 – 0.0669)
1HD-T (Others)	1,440	1.96 – 2.96 (0.0772 – 0.1165)




(n) Check the protrusion of the governor shaft.

**Protrusion: 0.5-2.0 mm (0.020-0.079 in.)**

## 18. ADJUST IDLE SPEED


(a) (w/ Dash Pot)

Using pliers, remove the dash pot cover.



(b) (w/ Dash Pot)

Fully loosen the dash pot adjusting screw.




(c) Measure the injection volume for each pump rpm.

Item	Adjusting lever angle	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)	Variation limit cc (cu in.)	Remarks
1PZ	Minus 12 – 22°	325	200	$q = 2.94 \sim 3.94$ (0.18 ~ 0.24)	0.4 (0.02)	Adjust
		300		More than $q$ Plus 0.5 (0.03)	–	–
		400		$q$ Minus 1.2 ~ 2.2 (0.07 ~ 0.13)	–	–
1HZ (M/T)	Minus 12 – 22°	375	200	$q = 2.3 \sim 3.3$ (0.14 ~ 0.20)	0.4 (0.02)	Pre-set
		350		More than $q$ Plus 0.5 (0.03)	–	–
		450		$q$ Minus 1.2 ~ 2.2 (0.07 ~ 0.13)	–	–
		325		2.60 ~ 3.60 (0.16 ~ 0.22)	0.4 (0.02)	Adjust
1HZ (A/T)	Minus 12 – 22°	375	200	$q = 2.3 \sim 3.3$ (0.14 ~ 0.20)	0.4 (0.02)	Pre-set
		350		More than $q$ Plus 0.5 (0.03)	–	–
		450		$q$ Minus 1.2 ~ 2.2 (0.07 ~ 0.13)	–	–
		375		1.64 ~ 2.64 (0.10 ~ 0.16)	0.4 (0.02)	Adjust

Cont'd

Item	Adjusting lever angle	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)	Variation limit cc (cu in.)	Remarks
1HD-T (Europe M/T)	Full position	400	200	9.32 ~ 11.72 (0.57 ~ 0.72)	–	–
	Minus 12 – 22°	325		$q = 3.70 \sim 4.70$ (0.23 ~ 0.29)	0.4 (0.02)	Adjust
		300		More than $q$ Plus 0.5 (0.03)	–	–
1HD-T (Europe A/T)	Full position	400	200	10.30 ~ 12.70 (0.69 ~ 0.77)	–	–
	Minus 12 – 22°	325		$q = 2.84 \sim 3.84$ (0.17 ~ 0.23)	0.4 (0.02)	Adjust
		300		More than $q$ Plus 0.5 (0.03)	–	–
1HD-T (Others M/T)	Full position	400	200	9.20 ~ 11.60 (0.56 ~ 0.71)	–	–
	Minus 12 – 22°	325		$q = 3.70 \sim 4.70$ (0.23 ~ 0.29)	0.4 (0.02)	Adjust
		300		More than $q$ Plus 0.5 (0.03)	–	–
1HD-T (Others A/T)	Full position	400	200	10.18 ~ 12.58 (0.62 ~ 0.77)	–	–
	Minus 12 – 22°	325		$q = 2.84 \sim 3.84$ (0.17 ~ 0.23)	0.4 (0.02)	Adjust
		300		More than $q$ Plus 0.5 (0.03)	–	–




(d) Adjust by turning the idle speed adjusting screw.

(e) (w/ Dash Pot)

Set the adjusting lever to the angle for the injection volume shown below.

Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1HZ	700	200	$q = 0.5 \sim 0.9$ (0.03 ~ 0.05)
1HD-T	400	200	$q = 0.1 \sim 0.3$ (0.01 ~ 0.02)




(f) (w/ Dash Pot)

Adjust the injection volume with the dash pot adjusting screw.

HINT: The stroke will decrease with turn to clockwise and increase with turn to counterclockwise.

Item	Pump rpm	No. of measuring strokes	Injection volume cc (cu in.)
1HZ	700	200	$q$ Plus 0.2 ~ 0.3 (0.01 ~ 0.02)
1HD-T	400	200	$q$ Plus 0.1 ~ 0.3 (0.01 ~ 0.02)

- (g) (w/ Dash Pot)  
Install the dash pot cover.




### 19. (w/ACSD)

#### ADJUST COLD STARTING SYSTEM


- (a) Remove the overflow screw and check the fuel temperature in the fuel pump.

**Fuel temperature: 15 - 35°C (59 - 95 °F)**


- (b) Set the set key of the pump drive shaft in a vertical or horizontal position.  
(c) Set the scale of the timer measuring device to zero.  
(d) Check the adjusting lever opening angle and consider this angle as zero.  
(e) Remove the metal plate between the cold starting lever and thermo wax plunger.





- (f) Torque the cold starting lever clockwise to approx. 50 kg-cm (43 in.-lb, 4.9 N-m) and keep the lever tightened for about 10 seconds. Then release the torque.




- (g) Measure the timer piston stroke.





(h) Adjust by turning the timer adjusting screw.


HINT: Screw in for stroke decrease.




## 20. (w/ ACSD) ADJUST FAST IDLE

(a) Measure the clearance between the adjusting lever and idle speed adjusting screw.

Item	Fuel temperature	Clearance
1PZ and 1HZ	15°C (59°F)	1.3 mm (0.051 in.)
	30°C (86°F)	0 mm (0 in.)
1HD-T	15°C (59°F)	1.6 mm (0.063 in.)
	40°C (104°F)	0 mm (0 in.)




(b) Adjust by turning the fast idle adjusting screw.



## 21. POST ADJUSTMENT CHECK


(a) Check that injection stops when the fuel cut solenoid harness is removed.

**Pump revolution: 100 rpm**




(b) Check the adjusting lever movement.

**Adjusting lever angle: 38-48°**



## 22. SEAL PARTS

Seal the maximum speed adjusting screw and full load set screws with new lead seals.




## 23. INSTALL TWO FUEL PIPES

**Torque:**

Inlet 250 kg-cm (18 ft-lb, 25 N-m)  
Outlet 225 kg-cm (16 ft-lb, 22 N-m)

## 24. INSTALL INJECTION PUMP STAY





## INSTALLATION OF INJECTION PUMP

(See page FU-27)

### 1. INSTALL INJECTION PUMP


**NOTICE:** Do not put the injection pump (with HAC, or for the 1 HD-T) at an angle more than 45° from the horizontal.

- (a) (1PZ and 1 HZ (M/T for Europe))  
Place the cylinder block insulator in position.
- (b) Install a new O-ring to the pump.
- (c) Apply a light coat of engine oil on the O-ring.
- (d) Align the set key on the drive shaft and groove of the injection pump drive gear.



- (e) Align the period lines (or matchmarks) of the injection pump and timing belt case.
- (f) Install the two nuts holding the injection pump to the timing gear case.

**Torque: 185 kg-cm (13 ft-lb, 18 N-m)**




- (g) Install the pump stay mount bolt.


**Torque: 700 kg-cm (51 ft-lb, 69 N-m)**

**NOTICE:** Before tightening to the standard torque, check whether the pumpstay is up against the pump bracket.


If there is a gap, loosen the bolts joining the pump stay to the cylinder block and set the pump stay against the pump bracket.







(h) Install a new O-ring to the injection pump drive gear.



(i) Install the injection pump drive gear set nut.

(j) Using SST, torque the nut.


SST 09330-00021

Torque: 1,000 kg-cm (72 ft-lb, 98 N·m)

2. CHECK INJECTION TIMING (See page EM-24)
3. INSTALL INJECTION PIPES  
(See step 3 on page FU-15)  
Torque:  

"IPZ and 1HZ	150 kg-cm (11 ft-lb, 15 N·m)
1HD-T	250 kg-cm (18 ft-lb, 25 N·m)
4. (w/ BACS)  
CONNECT BACS VACUUM HOSE
5. (w/ PCS)  
CONNECT PCS VACUUM HOSE
6. (1HD-T)  
CONNECT BOOST COMPENSATOR HOSE
7. CONNECT FUEL HOSES TO INJECTION PUMP
8. CONNECT INJECTION PUMP CONNECTOR
9. (w/ ACSD)  
CONNECT WATER BY-PASS HOSES TO THERMO WAX
10. (w/ A/C)  
CONNECT A/C IDLE-UP VACUUM HOSE
11. (A/T)  
CONNECT THROTTLE CABLE
12. CONNECT ACCELERATOR CONNECTING ROD
13. INSTALL NO.2 CAMSHAFT TIMING PULLEY  
(See step 4 on page EM-39)
14. INSTALL TIMING BELT  
(See steps 6 to 9 on pages EM-39 to 41)

15. FILL WITH ENGINE COOLANT (See page CO-5)
16. START ENGINE AND CHECK FOR FUEL LEAKS
17. CHECK IDLE SPEED AND MAXIMUM SPEED  
(See page EM-27)



## POWER CONTROL SYSTEM (PCS) (HDB30(w/ M/T) only)

### ON-VEHICLE INSPECTION


#### INSPECT POWER CONTROL SYSTEM (PCS)

- (a) Start the engine.
- (b) Depress the clutch pedal and check the operation of the actuator at each shift position.

#### Standard:

Shifting to 1st or Reverse.....Actuator not  
operating

Shifting to other positions.....Actuator operates



### INSPECTION OF POWER CONTROL SYSTEM (PCS) COMPONENTS

#### 1. INSPECT PCS VSV

##### A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between the terminals.


**Resistance (Cold): 33-39 Q**


If there is no continuity, replace the VSV.

##### B. Inspect VSV for ground

Using an ohmmeter, check that there is no continuity between each terminal and the body.


If there is continuity, replace the VSV.





### C. Inspect VSV operation


- (a) Check that air flows from pipes E to the filter.



- (b) Apply battery voltage across the terminals.

- (c) Check that air flows from pipe E to F.

If operation is not as specified, replace the VSV.



### 2. INSPECT SHIFT POSITION SWITCH

- (a) Check that there is no continuity between terminals when the switch is pushed (shift position 1st or reverse).
- (b) Check that there is continuity between terminals when switch is free (shift position others).

If continuity is not as specified, replace the switch.